

RULE 10-I

Oral authorization and acknowledgments between Foremen and Engineers for trains to pass "Red Conditional Stop" signs must be worded in the following forms:

Foreman's Response

"THIS IS S.P. FOREMAN IN CHARGE OF THE WORK BETWEEN MP AND MP S.P. TRAIN ORDER NO. WE ARE IN THE CLEAR AND YOU MAY PROCEED PAST THE RED CONDITIONAL STOP SIGN AND THROUGH THE LIMITS OF THE ORDER AT M.P.H."

Engineer's Response

"THIS IS ENGINEER S.P. TRAIN I MAY PROCEED PAST THE RED CONDITIONAL STOP SIGN AND THROUGH THE LIMITS OF ORDER NO. BETWEEN MP AND MP AT (Speed). REPEAT (Speed) MILES PER HOUR."

Foreman's Response

"S.P. TRAIN ORDER NO. BETWEEN MP AND MP, M.P.H. OK."

SPEED TABLE

TIME PER MILE	MILES PER HOUR	TIME PER MILE	MILES PER HOUR
41"	87.8	1'11"	50.7
42"	85.7	1'12"	50
43"	83.7	1'13"	49.3
44"	81.8	1'14"	48.6
45"	80	1'15"	48
46"	78.3	1'16"	47.4
47"	76.6	1'17"	46.8
48"	75	1'18"	46.2
49"	73.5	1'19"	45.6
50"	72	1'20"	45
51"	70.6	1'25"	42.4
52"	69.2	1'30"	40
53"	67.9	1'35"	37.9
54"	66.7	1'40"	36
55"	65.6	1'45"	34.3
56"	64.3	1'50"	32.7
57"	63.2	1'55"	31.3
58"	62.1	2'00"	30
59"	61	2'15"	26.7
1'00"	60	2'30"	24
1'01"	59	2'45"	21.8
1'02"	58.1	3'00"	20
1'03"	57.1	3'30"	17.1
1'04"	56.2	4'00"	15
1'05"	55.4	5'00"	12
1'06"	54.5	6'00"	10
1'07"	53.7	7'00"	8.6
1'08"	52.9	7'30"	8
1'09"	52.2	8'00"	7.5
1'10"	51.4	10'00"	6

SOUTHERN PACIFIC COMPANY



LOS ANGELES DIVISION SPECIAL INSTRUCTIONS

NO. 15

EFFECTIVE JANUARY 1, 1969

AT 12:01 A.M.,

PACIFIC STANDARD TIME

THESE INSTRUCTIONS CONSTITUTE A PART OF THE TIMETABLE CURRENTLY IN EFFECT

M. A. McINTYRE,
General Manager.

S. B. BURTON,
R. L. KING,
Assistant General Managers.

J. J. WILLIS,
General Superintendent of
Transportation.

O. D. GOODWILL,
Superintendent of Transportation.

J. H. LONG,
Superintendent.

SPECIAL INSTRUCTIONS—ALL SUBDIVISIONS

RULE A. Employes must know they have in their possession copy of Rules and Regulations of the Transportation Department Effective January 1, 1969.

RULE 10-G. On all branches except on Calexico Branch between Niland MP 667.4 and El Centro MP 698.90 an unattended red flag by day and, in addition, a red light by night will be placed to the right of main track in direction of approach at a distance of 1,000 feet from the point to be protected. A yellow signal will be displayed to right of track and a torpedo will be placed on rail one-half mile in advance of red signal. Flagman will not be provided. Trains stopped by these signals must be governed by signal or instructions from the foreman in charge.

Between the mileposts listed above the yellow flag and torpedo will be placed one and one-half miles in advance of the red flag.

RULES 10-G, 10-H and 10-I. When unattended red flags or red lights, yellow signals, red **CONDITIONAL STOP** signs and yellow **PROCEED PREPARED TO STOP** signs are displayed between siding switches, they must be duplicated to right of track in direction of approach. If clearance between siding and main track does not permit display of these signals to right of track in direction of approach, signals may be displayed to left of track in direction of approach. Display of these signals to the left of track in direction of approach must be respected as though they were displayed in accordance with these rules.

RULE 10-J. Speed signs prescribing an increase in speed will not be installed on branches. Speed Restrictions tables will indicate permissible speeds between mile post locations named.

RULE 26. On diesel fueling tracks, a blue light will not be attached to reflectorized "Men at Work" signs when displayed at night.

RULE S-72. Westward trains are superior to trains of the same class in the opposite direction.

RULE 105. Capacity of sidings column indicates length of train in feet that can be accommodated between fouling points.

Sidings designated "E" in capacity of sidings column are assigned for use by eastward trains; those designated "W" are assigned for use by westward trains. Those designated "N" for North and "S" for South are assigned for use by trains as shown in special instructions for the subdivision on which located.

RULE 505. AUTOMATIC BLOCK SIGNAL SYSTEM PUSH BUTTONS

Where signal protection is provided for movements from an adjacent track to main track, push buttons and pilot lights are installed in box near each of the two signals, with time-release feature, to clear signals on one track when the control circuit on the other track is occupied.

Train on main track to let train on siding pass may clear signal on siding by pressing button bearing number of signal on siding. Train on siding to let train on main track pass should not pass Approach Circuit sign, but when necessary to do so, may clear signal on main track by pressing button bearing number of signal on main track. Further instructions posted inside push button box.

ELECTRIC AND MECHANICAL SWITCH LOCKS

Where electric or mechanical switch locks are installed, be governed by instructions posted in telephone booths, on doors or in housings of electrical or mechanical switch locks.

RULE 663(b). INTERLOCKING

Operator may authorize movements under provisions of this rule after it has been ascertained indication lights on control panel are illuminated indicating dual control switches are in proper position and locked for movement without requiring dual control switches to be in hand position.

When indication lights on control panel are not illuminated, movements may be authorized under provisions of this rule; however, before making a facing point or trailing point movement over dual control switches, such switches must be placed in hand position, and locked until movement over switch has been completed. When movement has been completed, switch must be returned to normal position and selector lever restored to motor position and locked.

RULE 705. HOT BOX DETECTORS

Instructions follow for operation of hot box detector boxes when stopped by illuminated letter or flashing white light actuated by hot box detector device. These instructions are also posted inside detector boxes.

Hot box detector scanner sites have a white light continuously displayed on track side of instrument house, except when a hot bearing is detected, at which time light will start flashing. Crew members must keep a vigilant lookout for light and, when flashing, conductor and engineer must immediately orally compare observation when means of communication is available. Absence of white light must be promptly reported to Train Dispatcher.

When letter "H" is illuminated or it is known a hot bearing has been detected by crew member observing the flashing white light at scanner site, speed of train must be reduced to not exceeding 15 MPH until stop is made at location of readout indicator.

When letter "W" is illuminated train must stop and wait until indicator is extinguished or permission is obtained from train dispatcher to proceed. Telephone located near "W" indicator.

Numerals displayed by indicator inside of box indicate location of car with hot bearing in train. Top row indicates hot bearing on right side of train and lower row on left side of train in direction of movement. Numbers displayed on top row or bottom row indicate number of axles between hot bearing and rear of train. Indicator will display a maximum of four hot bearings on each side of train. All journals of car indicated by detector as well as each adjoining car must be inspected.

When H indicator indicates a hot journal on train and there is no count shown on hot bearing detector and red light below readout marked "Locator out of Service" is illuminated, all journals on train must be inspected.

After inspection has been completed train dispatcher must be notified of condition found. When it is safe to proceed, member of crew must push button below indicator panel to cancel numbers on the indicator. Case door must be closed and secured with switch lock.

When hot box detectors actuated, following information is to be reported at next terminal in telegraph message form addressed jointly to Superintendent, Division Engineer, Signal Supervisor, and Chief Dispatcher identified by symbol H.B.

1. Date and time stopped, and M.P. location.
2. Train identification.
3. Car number and location in train.
4. Box location (1, 2, 3 or 4 from trailing end of car in direction of movement, right or left side).
5. Disposition of car. (If set out, state where. If inspection shows that it was not necessary to set out even though journal was warm enough to activate the detector, advise what corrective action was taken to permit movement of car. If roller bearing equipped, so state.)
6. Report all cases where train passes over the detector without an indication having been displayed, but developing a hot box between detector and a point 20 miles beyond detector.

RULE 827. Engines running light on descending grade without dynamic brake in operation must stop a sufficient length of time to permit wheel heat radiation if there is indication of overheating. Stop need not be made if in the judgment of the engineer it is safe to proceed.

RULE 872. Enginemen when taking charge of through freight or passenger engines at San Luis Obispo, Santa Barbara, Los Angeles, Palmdale, Colton, Indio, and Yuma will consider engines as having been amply supplied with fuel and sand.

AIR BRAKE RULES

RULE 2. Engineers when taking charge of road engine at San Luis Obispo, Santa Barbara, Los Angeles, Palmdale, Colton, Indio, and Yuma will consider sanders are operating properly.

Enginemen taking charge of road engines at Taylor Roundhouse will consider that condensation has been drained from reservoirs, and from moisture and dirt collectors; and that communicating signal is operating and cut-out cocks are properly positioned on engines in passenger service.

RULE 2-A. On departure from locomotive maintenance facility, enginemen must determine by making running air brake test that the independent and automatic brakes are operating effectively.

RULE 2-B. Dynamic brake on head end of freight and mixed trains must not exceed three 8-axle units, four 6-axle units, six 4-axle units, or any combination thereof which totals 24 axles, except dynamic braking on EF 415A and B and EP 415A and B classes is limited to five units.

Dynamic brake must not be used when operating in multiple with engines other than SP or SSW units, unless equipped with dynamic brake interlock.

RULE 3. A full independent brake application on road locomotive classes EP 636, GF 628, GF 630, GF 633, EF 623, EF 630, EF 636, EF 850B results in a brake cylinder pressure of 72 psi. This brake cylinder pressure must be maintained to provide required braking power at very low speed or when stopped. Under no circumstances must self-lapping portion of independent brake valve be changed except to obtain brake cylinder pressure of 72 psi from a full independent brake application.

RULE 11. Cars equipped with brake cylinder release valve may have one or two operating release rods. Operating rods connected to brake cylinder release valve may be identified by stencil reading "Br.Cyl.Rel." or by a diamond shaped stencil or by noting that ends of release rod form a small closed circle. Air brakes can be released on cars equipped with a brake cylinder release valve by a hard momentary pull on release rod after brake pipe pressure has been depleted.

RULE 17. If at any time in engineer's judgment use of retaining valves is required, stop will be made and retaining valves turned up in accordance with his request.

FREIGHT TRAINS

RULE 22. Trainmen must not couple air hoses on outgoing trains at San Luis Obispo, Dolores, South Gate, Los Nietos, City of Industry, Palmdale, Colton, Indio, and El Centro until train is made up and caboose and engine on train.

Coupling engine on head end and caboose to rear of train is an indication that train is made up and yardmen or trainmen have completed their work. Yardmen or trainmen must not perform switching on, or couple other cars to a train on which the caboose and engine have been attached, without instructions from yardmaster, or proper authority, who will arrange to notify members of crew in advance.

Rule 23. The following series of cars are equipped with ABEL brake system which has automatic changeover feature to provide proper brake function when car is loaded and when empty:

- SSW 75700—75799 Gondolas
- SSW 78500—78599 Hoppers (Open Top)
- SP 333500—334399 Gondolas
- SP 337500—337599 Gondolas
- SP 345000—345669 Gondolas
- SP 354000—354399 Gondolas
- SP 463500—463999 Hoppers (Open Top)
- SP 467500—467549 Hoppers (Open Top)
- SP 480000—480193 Hoppers (Open Top)
- SP 491000—491059 Hoppers (Covered)
- SP 492000—492039 Hoppers (Covered)
- SP 500604 Flat Car
- SP 590000—590099 Flat Cars

MISCELLANEOUS

1. Helper service:

- (a) When helper engine is placed behind caboose, not more than two operating units nor 4000 operative horsepower will be used.
- (b) When helper engine is placed immediately ahead of caboose a combination of not more than 18 axles will be used.
- (c) Helper engines consisting of more than 12 axles must not be placed directly behind 80 foot or longer trailer flatcars.
- (d) When helper engine is placed directly ahead of caboose, additional helper must not be coupled behind caboose. Helper engines must be separated by at least 20 cars.
- (e) Air will be cut in on all helper engines, and engines must not be coupled or uncoupled while train is in motion.
- (f) When helper engine is shoving on ascending grade, throttle must be reduced as train speed reduces, then throttle regulated so that amperage will be approximately the same as indicated before train speed reduction.

2. Unless otherwise authorized, trains handling passenger cars with flat spots on wheels in excess of 3/4 inches in length must not exceed 10 MPH. When flat spots are not in excess of 3/4 inches long such cars may be operated at maximum authorized speeds.

3. Engines operated with engineer in other than lead unit in direction of movement, must not exceed 20 MPH when approaching highway or street crossing at grade, subject to further restrictions imposed by local conditions.

4. MAXIMUM SPEED PERMITTED WITH CERTAIN EQUIPMENT	MPH MAIN TRACKS OTHER THAN BRANCHES	MPH MAIN TRACKS ON BRANCHES
	Double or triple loads.....	..
Scale test cars, except:.....	40	30
SPMW 2024.....	65	49
Steel pile-drivers, except:.....	40*	30*
SPMW 4088 and 5479 (locomotive crane pile-driver).....	45*	35*
Relief outfits with steam derrick, except:.....	35	25*
(Relief outfits 7014 and 7025 must not be operated on any branch, except may be operated on Santa Paula Branch provided an empty 50-foot car is placed between crane and engine; on San Pedro Branch to MP 504.00; on Burbank Branch between Burbank and Canoga Park; on Santa Ana Branch and on Puente Branch).....	35*	25*
Locomotive cranes:		
with boom disconnected, heavy end forward..	45*	25*
except SPMW 743, 4020 and 4049.....	35*	25*
with boom disconnected, light end forward..	20*	15
with boom in place, either end forward.....	25*	15

*These speeds must not be exceeded, and on curves where authorized speed is more than 15 MPH speed must be reduced to 5 MPH less than shown in timetable and on speed signs.

SPECIAL INSTRUCTIONS—ALL SUBDIVISIONS

5. SPEED RESTRICTIONS FOR ENGINES: Maximum speed shown below is subject to further restriction applicable to certain territories as shown in Speed Restrictions for Trains:

Nominal classifications are descriptive of the engines as follows:

1st letter.....Builder: A Alco: B-BLH: E-EMD: F-Fairbanks-Morse: G-GE: K-Krauss-Maffei

2nd letter.....Type of service: F-Freight: P-Passenger: S-Switcher

1st number.....Number of axles

2nd and 3rd numbers..Horsepower (100)

Last letter.....Style of unit: A Car body type with control cab. B No control cab, No letter indicated road switcher type

In addition to the above, total length of unit in feet is shown below.

Nominal Class	Engine Number	Maximum Speed Except (l)	LENGTH (Feet)
AS 407-1.....	1000-1016.....	60	45
AS 409-1 to 5.....	1200-1281.....	60	46
AS 410-2 to 5, 6.....	1703-1845.....	60	46
AS 415.....	2400-2409.....	65	54
AS 416-C-1, 2, 3.....	2800-2805.....	75	54
AS 416-C 4, 5.....	2807-2812.....	65	57
AS 616.....	2852-2890.....	65	57
AS 418-1-6.....	2900-2936.....	70	57
AS 618-1.....	2950-2970.....	70	58
BS 410-2, 4.....	1856-1869.....	60	49
BS 412-1, 2.....	2100-2144.....	60	46
BS 615-B-1.....	5208-5220.....	35*	58
BS 616-2, 3, 5, 6.....	5233-5278.....	35*	58
ES 406-2, 3.....	1023-1032.....	45	44
ES 408-1 to 4.....	1100-1128.....	65	44
ES 408-B-1.....	1150-1153.....	65	44
ES 409-1, 2.....	1170-1179.....	65	44
ES 410-C-1, 2.....	1900-1903.....	65	44
ES 410-1.....	1904-1912.....	60	44
ES 410-2.....	1914-1953.....	65	44
ES 412-C-1 to 5.....	2200-2207.....	65	44
ES 412-1 to 5.....	2208-2293.....	65	44
ES 415.....	2450-2510.....	65	45
ES 615-1, 4.....	2700, 2702, 2703, 2716, 2722.....	55	61
ES 615-1 to 4.....	2701, 2704 to 2715, 2717 to 2721, 2723 to 2742.....	70	61
FS 412-1, 2, 3.....	2350-2374.....	60	49
FS 412-4, 5.....	2375-2394.....	60	46
GS 407-1, 6.....	5100-5120.....	55	37
EP 415A-1 to 4.....	354 to 356-6190, 6388-6445.....	79	51
EP 415A-5.....	6446 to 6461.....	79	55
EP 415AC-1.....	6462.....	70	55
EP 415B-1, 2, 3.....	8091-9303.....	79	50
EP 418-1 to 4.....	3000-3002, 3004 to 3009.....	79	56
EP 418-5.....	3010.....	70	56
EP 624A-1.....	6046 to 6054.....	79	70
EP 636-1.....	3200 to 3209.....	70	71
FP 624-1, 2.....	3020-3035.....	70	66
AF 420-1.....	4000-4009.....	70	57

Nominal Class	Engine Number	Maximum Speed Except (l)	LENGTH (Feet)
AF 624-C-1.....	5150-5159.....	75	57
AF 624-1.....	5160-5162.....	70	57
AF 628-1, 2.....	7100-7128.....	70	70
AF 630.....	7800-7814.....	70	70
EF 415C-1.....	304.....	70	60
EF 415A-4 to 9, 11..	6213-6470.....	70	56
EF 415AC-1, 2, 3....	925, 937, 951, 955 to 967.....	70	51
EF 415BC-1, 2, 3....	928, 932, 940, 952....	70	50
EF 415B-4 to 7, 9, 11, 13.....	8101-8305.....	70	50
EF 418A-1.....	600-629.....	70	50
EF 418B-1.....	702-722.....	70	50
EF 418-1 to 9.....	3400 to 3640, 3653 to 3727.....	70	56
EF 418-C-1, 2.....	3641-3652.....	70	56
EF 618-1 to 5.....	3800-3966.....	70	51
EF 420-C-1.....	4030.....	75	56
EF 420-1, 2.....	4031-4039.....	70	56
EF 420-1, 2.....	4040-4069.....	70	56
EF 423-C-1.....	5000-5009.....	70	56
EF 423-1.....	5010-5014.....	70	50
EF 425-C-1, 2, 3....	6500-6519, 6680-6681	70	56
EF 425-1, 2, 3, 4....	6520-6679.....	70	56
EF 625-1.....	6900-6928.....	70	61
EF 430-C-1.....	7600-7607.....	70	59
EF 623-1.....	70	66
EF 630-1, 2.....	8400-8488.....	70	66
EF 636-1, 2, 3, 4....	8800-8963.....	70	66
EF 636-C-1, 2.....	8964-8981.....	70	60
EF 850-B-1.....	9500-9502.....	70	88
GF 425-1, 2, 3.....	6700-6767.....	70	60
GF 428-1.....	7025-7028.....	70	60
GF 630-1.....	7900-7929.....	70	67
GF 850.....	9550-9552.....	70	84

#When operated in multiple unit control, on headend of train or running light and engineer is in other than the leading control cab in direction of movement, speed must not exceed 30 mph. 'A' type units (indicated by letter 'A' following classification numerals) operating in reverse as lead unit in direction of movement must not exceed 30 mph.

*Speed must not exceed 25 mph. on less than 90-lb. rail.

6. Diesel engines weighing 100,000 pounds or more moving dead in train will be placed first behind engine handling train; diesel engines weighing less than 100,000 pounds must be placed near rear of train.

Dead or disabled engines which require movement at reduced speed must not be handled in train until train-order designating maximum speed is issued.

7. OTHER MAXIMUM SPEEDS	MPH PASSENGER TRAINS	MPH FREIGHT AND MIXED TRAINS
	Trains of deadhead equipment with caboose... Passenger trains with caboose..... Engine and caboose only, except..... must not exceed speed for same engine running forward light.	65 65 ..

Light engines are authorized to operate at Column 1 speeds, not exceeding 70 MPH, except on descending grade without dynamic brake in operation, must not exceed Column 2 speeds.

When moving against current of traffic, or when movement is not protected by block signals, speed of passenger trains and light engines must not exceed 59 MPH, and speed of freight trains must not exceed 49 MPH, nor may speed exceed that applying to normal operation.

8. All cars handled in passenger trains must be equipped with steel-tired or all-steel wheels. Cars not so equipped must move in freight trains, passengers if any, to move on passenger trains.

Passenger carrying cars, baggage, express and other head-end cars, unless equipped with steel center sills and steel platforms must not be handled in passenger trains except on authority of Superintendent.

Freight cars must not be handled behind occupied passenger carrying cars, except in mixed trains in military or naval movements.

Baggage, express, mail, refrigerator or other head-end cars must not be handled on rear of passenger trains unless trainmen can pass through them.

Where mail, papers, or ice are to be dispatched from passenger trains at points where train does not stop, slow down sufficiently to permit safe dispatch without hazard, and stop at such stations for this purpose if train is moving on adjoining track between passenger train and point of exchange.

9. Freight and mixed trains containing no restricted cars are authorized to operate at column 1 speeds not exceeding 60 MPH (65 MPH when specifically authorized) consistent with local restrictions account grade and other conditions, provided trains do not exceed:

Number of Cars	Tons per Operative Brake
70.....	70
75.....	69
80.....	68
85.....	67
90.....	66
95.....	65
100.....	64
105.....	63
110.....	62
115.....	61
120.....	60
125.....	58
130.....	56
135.....	54
140.....	52
145.....	50

10. Public Utilities Commission of California Decision No. 67027, effective April 20, 1964, grants permission to operate open top freight cars of an overall height of 17 ft. 0 in. above top of rail in the State of California. If length of train permits, such cars shall be entrained at least five cars distant from the caboose and the engine.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

Handwritten notes and bleed-through from the reverse side of the page, including the word "Handwritten" and some illegible text.

SPECIAL INSTRUCTIONS—SANTA BARBARA SUBDIVISION

RULE: 10-J. Speed signs to left of track:

Eastward	Reading	Westward	Reading
		MP 254.04	25
		MP 264.71	60
MP 298.47	65—60	MP 407.23	75—60
		MP 462.40	60

RULE 26-A. Oxnard: Indicator lights above each end of tracks leading to Union Ice Co. dock governs movements on these tracks as follows:

- Green: Tracks may be used for train or switching movements.
- Yellow: Tracks may be entered, switched, and engines, cars or cabooses added or detached.
- Red: Tracks may be entered but cars on tracks must not be coupled to or moved. Trains made up on these tracks must not depart until it has been ascertained indicator displays green aspect.
- Not Lighted: Must be considered as displaying most restrictive indication and icing platform foreman must be contacted for instructions before cars are coupled or moved.

RULE 82-A. Train No. 51 is authorized to operate Los Angeles to Burbank Junction without obtaining clearance. All other Mojave Subdivision trains are authorized to operate between Los Angeles or Los Angeles Yard and Burbank Junction after having been issued San Joaquin Division clearance, and need not obtain clearance at Burbank Junction if train order signal displays green aspect.

Burbank Branch: After securing permission from operator Burbank Junction, extra trains may operate on Burbank Branch without obtaining clearance. Operator must receive authorization from train dispatcher before granting such permission. While there is an extra train operating on Burbank Branch, train dispatcher must not authorize another extra train to operate without first having an understanding, in accordance with the provisions of Rule 208-A, with all conductors and engineers operating or requesting permission to operate on the Burbank Branch.

RULE 83. Identification may be made on double track or in interlocking limits between San Luis Obispo and East San Luis Obispo, West Santa Barbara and East Santa Barbara, Los Angeles Yard and Burbank Junction, to be applied at end of double track or interlocking limits. Reduce speed sufficiently to permit identification and comply with Rule 14 (k).

When a regular train or section of schedule is checked at Los Angeles it will not be necessary to obtain check of the same train at Burbank Jct.

Ventura: After complying with Rule 513, trains or engines will move from Ventura Junction to Ventura by block signal indication, which will supercede the superiority of trains.

Extra trains or engines operating in below listed territories must register destination of trip (turning point), and date and time of departure in column captioned "Signals." When trip has been completed, date and time of arrival at initial station of trip must also be entered in column captioned "Signals." Engines en route into these territories must not leave the initial station until it has been ascertained from the train register that all preceding engines via the route to be used have completed their trips and registered time and date of arrival at initial station of trip accordingly:

Territory	Register Location
Ojai Branch:	
Ventura Junction-Ojai	Ventura Junction

RULE 83A. At the following stations only trains indicated will register:

- Guadalupe—originating or terminating
- Oxnard—originating or terminating
- Los Angeles Yard—originating or terminating.

RULE 83-B. At open train-order offices, trains may register by ticket as follows:

Santa Barbara. First-class and trains consisting of passenger equipment only.

RULE 93. Yard limits in which the provisions of Rule 93 will apply, are established at the following points:

West MP		East MP
249.56	San Luis Obispo	254.00
264.50	Oceano	267.00
275.20	Guadalupe	277.32
301.85	Surf	303.49
302.7	Surf (Lompoc and White Hills Branches)	End of Branches
369.16	Santa Barbara	373.71
397.13	Ventura	400.50
	" (Ojai Branch)	End of Branch
406.61	Oxnard	409.12
402.96	Montalvo (Santa Paula Branch)	404.83
423.54	Fillmore	425.62
412.57	Santa Paula	416.53
446.06	Chatsworth (Burbank Branch)	446.35
449.37	Saugus	451.64
448.17	" (Santa Paula Branch)	
444.7	Chatsworth	462.00
462.32	Los Angeles (Coast line)	
471.20	" (S. J. Valley-Alhambra line)	488.69
466.19	" (Burbank Branch)	

RULE D-97. Applies between San Luis Obispo and East San Luis Obispo, between West Santa Barbara and East Santa Barbara and between Burbank MP 473.28 and Los Angeles MP 479.31.

RULE 99. Flag protection to rear is not required on Burbank Branch.

Between yard limits signs Burbank Jct., MP 462.00-MP 462.32, engines may proceed without train order authority under the protection of flagman as prescribed by Rule 99.

RULE 103-A. Automatic crossing gates.

Following crossings protected by gates with control circuits located within short distance of crossings.

Station	Location	MP
*Lompoc	"A" Street	312.8
**Santa Barbara	State Street	370.80
***Burbank	Allen Avenue	473.15

*Stop signs installed. Crossing must not be entered until gates are down. Gates may be lowered manually by inserting switch key in receptacle. Turn key one half turn to right. Key may then be removed but crossing must be occupied within 45 seconds or gates will raise.

**Eastward trains making station stop must stop west of marker post located just west of crossing. When such trains are ready to depart, gates must be lowered manually by inserting switch key in receptacle located west of crossing adjacent to Eastward Main Track, and turning one-half turn to right. Key may then be removed but track east of marker post must be occupied within one minute or gates will raise.

Crossing protection signal will cut out if engines or cars moving toward crossing occupy track between "APPROACH CIRCUIT" signs and aluminum marker post for more than two minutes and member of crew must protect traffic before moving over crossing.

***Eastward trains stopped by interlocking signals at MP 473.15 must stop at least 100 feet west of Allen Avenue to permit crossing gates to raise. When proceed indication is received whistle must be sounded for one second to actuate gates. Sound detector microphone located west of Allen Avenue.

Trains must stop and traffic on highway be protected by member of crew over the following crossings:

Santa Barbara: Milpas Street on round house lead.

Limco: Telegraph Road on Limoneria Spur.

Santa Paula Branch:

*Edison Spur, MP 446.20, over Telegraph Road. (PUC requires trains to stop and member of crew to protect traffic before movement is made).

*Movement to be made only during daylight hours.

RULE 104. The normal position of rigid switches at junction points is as follows:

- Surf.....Middle track, for Lompoc Branch.
- White Hills Jct....White Hills Branch, for Lompoc-Surf line.
- Ventura Jct.....Ojai Br., for Coast line.
- Montalvo.....Santa Paula Br., east leg of wye.
- Chatsworth.....Burbank Br., Main track.
- Burbank.....Burbank Br., drill track.
- Saugus.....Santa Paula Br., westward siding.

Gemco: Deraill on GM track No. 7 electrically locked. General Motors Plant Protection Department must be notified to release deraill before it can be thrown.

RULE 105. Trains entering siding equipped with spring switch must not pass home signal until switch has been lined for movement.

Callender: Siding extends from Signal 2696 to cross-over just west of Signal 2708.

Oxnard: West switch to siding located at Signal 4078. Inside switch on siding must be left lined for drill track.

RULE 107. Station train indicators are provided in approach to the following station:

	Westward
.....	Glendale (MP 477.70)

When illuminated this indicator will convey the following information:

TRAIN—Train at platform on opposite track.

CLEAR—Indicator in service.

Glendale: When westward station train indicator is illuminated displaying "TRAIN," westward trains or engines must not proceed west of Signal 4775 until eastward train at the station has cleared, unless it is known that Eastward Track is occupied by a train not receiving or discharging traffic.

RULE 208. Third, fourth and fifth paragraphs will not apply to westward trains entering siding at Burbank Jct. Trains entering siding Burbank Jct. must not foul main track until it has been ascertained that any train orders delivered restricting their movement at that station have been fulfilled.

RULE 211. To enable train dispatcher to advance a westward train beyond Burbank Junction where it is restricted for an opposing or following train, operator after receiving verbal authority from train dispatcher will clear interlocking signal located at MP 471.80 for movement on main track on route desired, which will be an indication to an approaching train that orders have been issued authorizing movement to the next station at least, against and ahead of superior trains, and will not require the issuance of Form "N" Train Order or the blinking of red light in light type train order signal several times.

RULE 221.

TRAIN ORDER OFFICES:

Burbank Junction—westward trains only.

Burbank Junction—Train-order signal on north side of track No. 1 will govern movements on track No. 1. Train-order signal on south side of track No. 2 will govern movements on track No. 2.

Ventura—trains originating only.

Santa Barbara—train-order office located at freight station. Santa Barbara—Crews of westward passenger trains will receive orders at train-order office and deliver them to relieving crew.

RULE D-251. Will apply as follows:

Both tracks between San Luis Obispo and East San Luis Obispo.

Both tracks between West Santa Barbara and East Santa Barbara.

Both tracks between Burbank MP 473.28 and Los Angeles MP 479.31.

RULE 292.

San Luis Obispo: When eastward "SA" signal at west end of double track MP 251.75 displays stop indication, train or engine after stopping may proceed without calling train dispatcher if flashing white signal is also displayed.

RULE 306. The following block signals equipped with triangular plate displaying the letter "P" have included in their control limits some special protective device:

Eastward Signal	Protection	Westward Signal
	Spring switch, east end double track, East San Luis Obispo.....	P-2549
P-2598	Collision detector, Tiber underpass, MP 259.83.....	P-2597
P-2608	Flood detector, second Villa Creek bridge 261.37.....	P-2615
P-2838	Mud slide detector fence, Shuman.....	P-2851
P-2940	Fire detector, Los Alamos bridge, Narlon.....	P-2955
P-3020	Spring switch west end siding, Surf.....	
	Spring switch east end siding, Surf.....	P-3033
P-3056	Slide detector fence, MP 306.13.....	P-3067
P-3164	Spring switch, west end siding, Sudden.....	
	Spring switch, east end siding, Sudden.....	P-3177
P-3192	Fire detector, Jalama, Canon bridge, Jalama.....	P-3207
P-3214	Slide detector fence, MP 321.50.....	P-3227
	Spring switch, east end siding, Concepcion.....	P-3253
P-3690	Spring switch, end double track, West Santa Barbara.....	
	Spring switch, east end double track, Santa Barbara.....	
	Spring switch, east end freight lead, Santa Barbara.....	P-3723
	Spring switch, east end siding, Ortega.....	P-3775
P-3844	Slide detector fence, MP 385.10.....	P-3871
P-3872	Slide detector fence, MP 387.20—MP 387.70.....	P-3885
P-3972	Dragging Equipment Detector, MP 394.22.....	
	Dragging Equipment Detector, MP 401.28.....	P-3981
	Spring switch, east end siding, Ventura.....	P-3993
	Spring switch, east end siding, Oxnard.....	P-4089
	Spring switch, east end siding, Camarillo.....	P-4173
	Spring switch, east end siding, Moorpark.....	P-4275
	Spring switch, east end siding, Santa Susana.....	P-4377
P-4362	Spring switch, west end siding, Santa Susana.....	
P-4428	Falling Rock Detector, Tunnel 27, MP 443.....	P-4431
P-4452	Spring switch, west end siding, Chatsworth.....	
P-4460	High water detector.....	P-4471
	Chatsworth MP 446.40.....	
P-4470	Barricade Detector MP 447.2.....	P-4481
P-4470	Barricade Detector MP 447.8.....	P-4481
P-4480	Barricade Detector MP 448.0.....	P-4493
P-4504	Barricade Detector MP 450.7.....	P-4517
P-4554	Barricade Detector MP 456.3.....	P-4567
P-4592	Barricade Detector MP 460.2.....	P-4603

Ventura: Light type indicators on masts of Signals 3972 and 3981, are dragging equipment indicators.

They will display red aspect with signal at "STOP" position when actuated by dragging equipment detectors, and lunar aspect when not actuated.

Crews of trains stopped by Signals 3972 and 3981 with red indicator light illuminated will inspect their train for dragging equipment. Indicator lights must be changed to lunar by pressing push button located in box at Signals 3972 and 3981.

RULE 516.

Overlap posts:

Grover Eastward trains
Bromela Westward trains

RULE 538. SPRING SWITCHES

Spring switches equipped with facing point locks are located as follows:

Location	Normal Position
San Luis Obispo	End double track Westward track
Surf	West end siding Main track
Surf	East end siding Main track
Sudden	West end of siding Main track
Sudden	East end of siding Main track
Concepcion	East end of siding Main track
West Santa Barbara	End of double track Eastward track
East Santa Barbara	End of double track Westward track
East Santa Barbara	East end freight lead Main track
Ortega	East switch of siding Main track
Ventura	East switch of siding Main track
Oxnard	East switch of siding Main track
Camarillo	East switch of siding Main track
Moorpark	East switch of siding Main track
Santa Susana	West end siding Main track
Santa Susana	East switch of siding Main track
Chatsworth	West switch of siding Main track

Spring switches not equipped with facing point locks are located as follows:

East San Luis Obispo	End double track Westward track
East San Luis Obispo	West end siding Siding

RULE 605. INTERLOCKING

Burbank Junction: Limits extend on Santa Barbara Subdivision to signal bridge MP 462.42, on Mojave Subdivision to eastward interlocking signal MP 471.35 and on track No. 1 and track No. 2 to MP 473.28.

No. 1 track—to north
No. 2 track—to south

When interlocking signals within these limits display STOP indication, member of crew must contact Operator Burbank Junction.

All crossovers within these limits and east end of coast siding are equipped with dual control switches under control of Operator Burbank Junction. When necessary to hand operate dual control switches, Rule 772 will govern. Wherein Rule 772 the term "Train Dispatcher" is used, it has reference to Operator Burbank Junction.

Hand throw switches on Track No. 1 at MP 471.60 and MP 472.55 and on Track No. 2 at MP 471.60, MP 472.35 and MP 472.45 are equipped with electric locks. Lock box doors on these switches must not be opened without permission from Operator Burbank Junction.

Dayton Avenue Tower: Limits extend on main tracks from interlocking signal bridge MP 479.31 to signal bridge No. 4, MP 481.44; on yard tracks from interlocking signals located on east end of C Yard 1, 2 and 3, east end of yard leads No. 17 and No. 20 to interlocking signal located at the east end of the Midway bridge; and from interlocking signals located at the west end of C Yard 1 and the east end of A Yard 1 to respective power operated crossover switches to the main track.

Crossovers between MP 479.31 and MP 479.51 equipped with dual control switches. Instructions for operation posted in phone booth.

Bottom unit of interlocking signals on track No. 1 C Yard and track No. 1 A Yard may display lunar aspect. When lunar aspect is displayed train or engine may proceed without stopping at restricted speed within interlocking limits.

When interlocking signals display "STOP" indication, member of crew must contact Dayton Tower.

Mission Tower: Limits extend on both tracks of East Bank line from interlocking signals located 300 feet west of East Bank Jct. switches to westward interlocking signals located on Signal Bridge No. 2; on both tracks of River Station line to interlocking signals located 250 feet west of Naud Jct. switch; on Colton Subdivision on Westward Track to interlocking signal located 300 feet east of Taylor Jct. and on Eastward Track from switches at MP 482.85 to interlocking signals located 400 feet east of Taylor Jct.

Signal just west of tower building and adjacent to Track No. 55 has white disk attached to mast. Signal is to right of two converging tracks, and governs movement on either track.

RULE 663(b). Mission Tower: Following addition applies, "Upon receiving oral authority of operator or signal maintainer."

RULE 669. Dayton Ave. Tower and Mission Tower: One long sound of tower air whistle requires all movements through plant to stop immediately and remain standing until authorized by operator to resume movement.

RULE 705. HOT BOX DETECTORS

Illum. Letter	On Signal	Approaching	Location of Readout
H	2709	Callender	MP 269.6 Callender
W	2728	Guadalupe	
W	2741	Bromela	
H*	MP 274.5	Guadalupe	MP 275.8 Guadalupe
H	3097	Honda	MP 306.7 Honda
W	3114	Sudden	
W	3133	Honda	
H	3150	Sudden	MP 317.5 Sudden
W	3844	Punta	
H	3847	Carpinteria	MP 381.5 Carpinteria
W	3871	Punta	
H	3886	Seacliff	MP 389.6 Seacliff
W	4226	Moorpark	
H	4227	Somis	MP 419.5 Somis
W	4253	Somis	
H	4264	Moorpark	MP 427.4 Moorpark

*Displays flashing white light when "H" illuminated.

SCANNER SITE

MP	Direction	Location
273.0	East and West	Callender-Guadalupe
312.5	East and West	Honda-Sudden
386.4	East and West	Carpinteria-Seacliff
424.4	East and West	Somis-Moorpark

Refer to Rule 705 All Subdivisions.

RULE 740. ABSOLUTE PERMISSIVE BLOCK.
Limits extend between Oxnard MP 407.14 and Montalvo MP 403.07.

When absolute signals at each end of APB limits display stop indication, trains or engines must obtain permission from operator Oxnard before proceeding.

Trains or engines must not enter main track or use main track switches within these limits without first obtaining permission from operator Oxnard.

When necessary to perform switching within these limits, Rule 765 will govern. Wherein Rule 765 the term "train dispatcher" is used, it has reference to operator Oxnard within these limits.

Operator Oxnard must obtain authorization from train dispatcher before granting work limits and clock time limits, or authorizing trains or engines to enter or move on main track within these limits.

Rule 744 will not apply within these limits.

GENERAL REGULATIONS

RULE 837. South Vandenberg Air Force Base—United States Government Tracks. Switching movements must be made with air brakes cut in on all cars. Cars must not be detached while in motion. Cars that are spotted on military tracks must be left in spurs protected by derails.

Engines must not handle more than four cars at any one time.

Engines handling cars must be on descending end of grade.

Not less than two hand brakes must be set on cars left on interchange tracks.

All hand brakes must be set on cars left in spurs protected by derails.

AIR BRAKE RULES

RULE 24-B. San Luis Obispo and Santa Barbara: Incoming engineer, after completing stop, must make a full service brake application leaving brakes applied. When outgoing crew takes charge of train on arrival or otherwise is assured, upon request, that continuity of brake pipe has not been disturbed, engineer will release brakes and proceed.

MISCELLANEOUS

1. Engines listed must not operate on tracks shown below:

Class of Engine	Restricted Tracks
All Engines	Oxnard-Track No. 3, Ventura County RR. Oxnard-Ventura County RR tracks— must not go beyond 250 feet east of the east switch of track VC 9.

2. Gemco: When shoving cars into Tracks Nos. 5, 6, 7, 8, 9 and 10 at General Motors plant, air must be cut in on all cars.

During plant hours, 7:00 AM to 1:30 AM, movement must be stopped, and crossing inside General Motors plant on Tracks Nos. 6, 7, 8 and 9 protected by a member of crew.

Public Utilities Commission orders require that all cars and engines shall be brought to a stop not more than 100 feet or less than 10 feet before entering building Tracks Nos. 6, 7 and 8 at General Motors Corp. Crews are prohibited from riding on cars in Tracks Nos. 6, 7 and 8 while entering or inside of plant building account overhead impaired clearance.

3. Santa Paula Branch: Watch for high water at bridge 427.40. Approach with caution, looking out for obstruction on tracks, stopping if necessary to make examination before proceeding.

4. Tunnel 26: Switches controlling lights in this tunnel are located at the east and west portals. Lights must be extinguished when not in use.

5. Load limit (car and contents):

*San Luis Obispo-Los Angeles	263,000 pounds
Lompoc and White Hills Branches	240,000 pounds
**Ojai Branch	240,000 pounds
Santa Paula Branch	240,000 pounds
Burbank Branch	240,000 pounds

*Gross weight of 315,000 pounds applies to uniformly loaded four axle cars with minimum axle spacing of 6 feet 0 inches and minimum distance of 37 feet 0 inches between truck centers; also, with wheels 38 inches or more in diameter.

**Ventura Junction to Nitroshell 315,000 pounds when meeting above requirements.

Unless authorized by Superintendent, heavier loads must not be handled.

6.

LOCATION OF OVERHEAD AND SIDE STRUCTURES NOT STANDARD CLEARANCE ON MAIN TRACK AND SIDINGS

MP	Location	Description
261.37	Pismo	Villa Creek Bridge Side
262.68	Pismo	Villa Creek Bridge Side
265.57	Oceano	Overhead Crossing . Overhead
266.37	Oceano	Arroyo Grande River Bridge Side
357.77	Ellwood	Overhead Crossing . Overhead
394.83	East of Dulah	Overhead Crossing . Overhead
396.61	West of Ventura Jct.	N. Fork Ventura River Bridge Side
396.87	West of Ventura Jct.	Ventura River Bridge . . . Side
440.28	East of Santa Susana	Overhead Crossing . Overhead
441.20	East of Santa Susana	Tunnel No. 26 Overhead and Side
442.90	East of Santa Susana	Tunnel No. 27 Overhead and Side
443.90	East of Santa Susana	Tunnel No. 28 Overhead and Side
415.40	East of Santa Paula	Santa Paula River, Bridge Side
423.00	West of Fillmore	Sespe Creek Bridge, Overhead and Side
423.00	East of Piru	Piru Creek Bridge Overhead and Side
445.68	East Newhall Ranch	Overhead Crossing . Overhead
446.16	East Newhall Ranch	Santa Clara River Bridge Overhead and Side

7.

SPEED RESTRICTIONS FOR OTHER THAN MAIN TRACKS	With Caution Not Exceeding MPH
Through sidings	15
Through yard and other tracks, wyes, balloon tracks, crossovers, turnouts and slip switches	10
On Limoneria spur, Limco, on tangent	25
" " on curves	10
On VC yard tracks, Oxnard, when shoving.	10
On Vandenberg AFB Track Tangair (MP 297.4) to Helium Spur	30
Crossovers MP 471.50	35
Crossovers MP 473.20	25
Crossovers MP 479.41	15

SPECIAL INSTRUCTIONS—SANTA BARBARA SUBDIVISION

SPEED RESTRICTIONS FOR TRAINS: Maximum speed of trains in territory shown below is subject to further restrictions applicable to engines in the train as shown in **SPEED RESTRICTIONS FOR ENGINES** appearing on page 4, and **MAXIMUM SPEED PERMITTED WITH CERTAIN EQUIPMENT** and **OTHER MAXIMUM SPEEDS** appearing on pages 3 and 4 of Special Instructions for All Subdivisions. Speed must be further reduced as prescribed by speed signs, except as specifically authorized by Special Instructions herein, or by timetable bulletin.

All trains must run carefully during and after heavy storms, particularly when the track is apt to be affected. When fog, storms or other conditions obscure track or signals, speed of trains must be so reduced as to permit strict observance of signals and **INSURE SAFETY, REGARDLESS OF TIME.**

TERRITORY			PASSEN- GER TRAINS	FREIGHT AND MIXED	TERRITORY			PASSEN- GER TRAINS	FREIGHT AND MIXED
MP	MP	Column:	1	2	MP	MP	Column:	1	2
EASTWARD, SAN LUIS OBISPO TO SANTA BARBARA:					WESTWARD, SANTA BARBARA TO SAN LUIS OBISPO:				
252.10 to 253.29			25	25	370.70 to 370.60			20	20
253.29 to 254.86			35	35	370.60 to 368.32			50	50
254.86 to 258.50			60	60	368.32 to 368.28			35	35
258.50 to 259.80			35	30	368.28 to 367.00			70	60
259.80 to 261.18			40	30	367.00 to 357.76			79	60
261.18 to 262.30			30	30	357.76 to 356.85			60	60
262.30 to 263.95			60	60	356.85 to 354.36			79	60
263.95 to 267.94			79	60	354.36 to 354.17			75	60
267.94 to 269.00			40	40	354.17 to 348.80			79	60
269.00 to 275.61			70	60	348.80 to 348.13			60	60
275.61 to 277.00			50	50	348.13 to 347.40			45	45
277.00 to 279.51			60	60	347.40 to 344.77			55	55
279.51 to 280.00			50	50	344.77 to 342.00			70	60
280.00 to 283.24			79	60	342.00 to 338.60			79	60
283.24 to 287.00			40	40	338.60 to 336.19			60	60
287.00 to 291.00			55	55	336.19 to 335.67			45	45
291.00 to 291.32			45	45	335.67 to 333.30			65	60
291.32 to 294.40			79	60	333.30 to 333.05			55	55
294.40 to 295.80			60	60	333.05 to 328.26			60	60
295.80 to 296.08			50	50	328.26 to 325.66			70	60
296.08 to 299.57			55	55	325.66 to 325.36			55	55
299.57 to 300.20			50	50	325.36 to 323.12			70	60
300.20 to 304.40			60	60	323.12 to 321.87			45	45
304.40 to 306.10			55	55	321.87 to 318.20			50	50
306.10 to 309.00			65	60	318.20 to 312.90			79	60
309.00 to 311.81			50	50	312.90 to 311.81			70	60
311.81 to 312.90			70	60	311.81 to 309.00			50	50
312.90 to 318.20			79	60	309.00 to 306.10			65	60
318.20 to 321.87			50	50	306.10 to 304.40			55	55
321.87 to 323.12			45	45	304.40 to 300.20			60	60
323.12 to 325.36			70	60	300.20 to 299.57			50	50
325.36 to 325.66			55	55	299.57 to 296.08			55	55
325.66 to 328.26			70	60	296.08 to 295.80			50	50
328.26 to 333.05			60	60	295.80 to 294.40			60	60
333.05 to 333.30			55	55	294.40 to 291.32			79	60
333.30 to 335.67			65	60	291.32 to 291.00			45	45
335.67 to 336.19			45	45	291.00 to 287.00			55	55
336.19 to 338.60			60	60	287.00 to 283.24			40	40
338.60 to 342.00			79	60	283.24 to 280.00			79	60
342.00 to 344.77			70	60	280.00 to 279.57			50	50
344.77 to 347.40			55	55	279.57 to 277.00			60	60
347.40 to 348.13			45	45	277.00 to 275.61			50	50
348.13 to 348.80			60	60	275.61 to 269.00			70	60
348.80 to 354.17			79	60	269.00 to 267.94			40	40
354.17 to 354.36			75	60	267.94 to 263.95			79	60
354.36 to 356.85			79	60	263.95 to 262.30			60	60
356.85 to 357.76			60	60	262.30 to 261.18			30	30
357.76 to 367.00			79	60	261.18 to 259.80			50	35
367.00 to 368.28 (end double track)			70	60	259.80 to 258.50			35	30
368.28 to 368.32			35	35	258.50 to 254.86 (end double track)			60	60
368.32 to 370.60			50	50	254.86 to 253.29			35	35
370.60 to 370.70			20	20	253.29 to 252.10			25	25

Freight and mixed trains are authorized to operate at Column 1 speed not exceeding 65 MPH when meeting requirements as outlined on page. 5

SPECIAL INSTRUCTIONS—SANTA BARBARA SUBDIVISION

SPEED RESTRICTIONS FOR TRAINS: Maximum speed of trains in territory shown below is subject to further restrictions applicable to engines in the train as shown in **SPEED RESTRICTIONS FOR ENGINES** appearing on page 4, and **MAXIMUM SPEED PERMITTED WITH CERTAIN EQUIPMENT** and **OTHER MAXIMUM SPEEDS** appearing on pages 3 and 4 of Special Instructions for All Subdivisions. Speed must be further reduced as prescribed by speed signs, except as specifically authorized by Special Instructions herein, or by timetable bulletin.

All trains must run carefully during and after heavy storms, particularly when the track is apt to be affected. When fog, storms or other conditions obscure track or signals, speed of trains must be so reduced as to permit strict observance of signals and **INSURE SAFETY, REGARDLESS OF TIME.**

TERRITORY			PASSENGER TRAINS	FREIGHT AND MIXED	TERRITORY			PASSENGER TRAINS	FREIGHT AND MIXED
MP	MP	Column:	1	2	MP	MP	Column:	1	2
EASTWARD, SANTA BARBARA TO LOS ANGELES:					WESTWARD, LOS ANGELES TO SANTA BARBARA:				
370.70 to 372.27 (Santa Barbara)			20	20	482.80 to 482.18 (Los Angeles)			12	12
372.27 to 383.66			55	55	482.18 to 481.90			15	15
383.66 to 384.40			45	45	481.90 to 481.69 (East Bank Jct.)			20	20
384.40 to 387.70			50	50	481.69 to 481.67 (North Main St.)			15	15
387.70 to 390.84			65	60	481.67 to 480.00			20	20
390.84 to 391.23			50	45	480.00 to 477.34			40	40
391.23 to 392.23			60	60	477.34 to 471.49 (462.61) (Burbank Jct.)			50	50
392.23 to 396.66			70	60	Through crossover east of Junction			35	35
396.66 to 397.08			45	45	462.61 to 462.38			40	40
397.08 to 398.20 (Ventura)			25	20	462.38 to 444.39			60	60
398.20 to 399.60			65	60	444.39 to 440.90			40	40
399.60 to 402.10			79	60					
402.10 to 402.38			65	60	440.90 to 437.80			60	50
402.38 to 405.27			79	60	437.80 to 434.35			79	50
405.27 to 405.66			60	50	434.35 to 429.82			65	50
405.66 to 407.23			75	55	429.82 to 429.45			55	50
407.23 to 408.08			35	35	429.45 to 418.00			70	60
408.08 to 414.85			79	60	418.00 to 415.36			79	60
414.85 to 415.36			60	60	415.36 to 414.85			60	60
415.36 to 418.00			79	60	414.85 to 408.83			79	60
418.00 to 429.45			70	60	408.83 to 408.08			79	55
429.45 to 429.82			55	55	408.08 to 407.23			35	35
429.82 to 434.35			65	60	407.23 to 405.66			75	60
434.35 to 437.80			79	60	405.66 to 405.27			60	50
437.80 to 440.90			60	60	405.27 to 402.38			79	60
440.90 to 444.39			40	40	402.38 to 402.10			65	60
444.39 to 460.00			60	60	402.10 to 399.60			79	60
460.00 to 462.38			60	50	399.60 to 398.95			65	60
462.38 to 462.61 (471.49) (Burbank Jct.)			40	40	398.95 to 398.20			65	45
Through Crossovers east of Junction			35	35	398.20 to 397.08 (Ventura)			25	20
471.49 to 477.34			50	50	397.08 to 396.66			45	45
477.34 to 480.60 (Dayton Ave. Tower)			40	40	396.66 to 392.23			70	60
480.60 to 481.67			20	20	392.23 to 391.23			60	60
481.67 to 481.69 (North Main St.)			15	15	391.23 to 390.84			50	45
481.69 to 481.90 (East Bank Jct.)			20	20	390.84 to 387.70			65	60
481.90 to 482.18			15	15	387.70 to 384.40			50	50
482.18 to 482.80 (Los Angeles)			12	12	384.40 to 383.66			45	45
					383.66 to 373.02			55	55
					373.02 to 372.27			55	45
					372.27 to 370.70 (Santa Barbara)			20	20

Freight and mixed trains are authorized to operate at Column 1 speed not exceeding 65 MPH when meeting requirements as outlined on page 5.

SPECIAL INSTRUCTIONS—SANTA BARBARA SUBDIVISION

SPEED RESTRICTIONS FOR TRAINS: Maximum speed of trains in territory shown below is subject to further restrictions applicable to engines in the train as shown in **SPEED RESTRICTIONS FOR ENGINES** appearing on page 4, and **MAXIMUM SPEED PERMITTED WITH CERTAIN EQUIPMENT** and **OTHER MAXIMUM SPEEDS** appearing on pages 3 and 4 of Special Instructions for All Subdivisions. Speed must be further reduced as prescribed by speed signs, except as specifically authorized by Special Instructions herein, or by timetable bulletin.

All trains must run carefully during and after heavy storms, particularly when the track is apt to be affected. When fog, storms or other conditions obscure track or signals, speed of trains must be so reduced as to permit strict observance of signals and **INSURE SAFETY, REGARDLESS OF TIME.**

TERRITORY		FREIGHT AND MIXED	TERRITORY		FREIGHT AND MIXED
MP	MP		MP	MP	
EASTWARD, SURF TO WHITE HILLS:			WESTWARD, WHITE HILLS TO SURF:		
302.91 to 303.31 (junction switch and wye)		10	315.93 to 312.94		10
303.31 to 308.93		35	313.25 to 312.90		10
308.93 to 312.90		20	312.90 to 308.93		20
312.90 to 313.25		10	308.93 to 303.31		35
312.94 to 316.93		10	303.31 to 302.91		10
EASTWARD, VENTURA JCT. TO OJAI:			WESTWARD, OJAI TO VENTURA JCT.:		
397.30 to 398.29 (Ventura)		10	412.30 to 408.00		20
398.29 to 407.00		20	408.00 to 407.00		10
407.00 to 408.00		10	407.00 to 398.29		20
408.00 to 412.30		20	398.29 to 397.30 (Ventura)		10
EASTWARD, MONTALVO TO SAUGUS:			WESTWARD, SAUGUS TO MONTALVO:		
402.94 to 408.00		30	448.62 to 448.42		20
408.00 to 411.00		40	448.42 to 441.96		30
411.00 to 412.80		30	441.96 to 431.62		25
412.80 to 415.30 (Santa Paula)		15	431.62 to 415.30		30
415.30 to 431.62		30	415.30 to 412.80 (Santa Paula)		15
431.62 to 441.96		25	412.80 to 411.00		30
441.96 to 448.42		30	411.00 to 408.00		40
448.42 to 448.62		20	408.00 to 402.94		30
EASTWARD, CHATSWORTH TO BURBANK VIA VAN NUYS:			WESTWARD, BURBANK TO CHATSWORTH VIA VAN NUYS:		
445.50 to 446.27		25	466.81 to 466.12		25
446.27 to 457.39		30	466.12 to 466.02		10
457.39 to 457.41 (Sepulveda Blvd.)		10	466.02 to 457.41		25
457.41 to 466.81		25	457.41 to 457.39 (Sepulveda Blvd.)		10
			457.39 to 446.27		30
			446.27 to 445.50		25

Trains must not exceed 10 MPH entering Vanowen Street crossing at Canoga Park, MP 449.60 and Highway 101 at Montalvo, MP 403.30.

Trains with class of engine shown below are further restricted between points shown, as follows:

	OJAI BRANCH	SANTA PAULA BRANCH				BURBANK BRANCH
	MP 403.6 408.4	MP 403.30 408.00	MP 411.00 431.48	MP 140.15 443.97	MP 443.97 448.62	MP 446.00 454.50
EF-418, EP-418	20			20		30
EF-420, EF-418				25		
AS-418	15	25	25	15	25	25
EF-415, EP-415				15		

RULE 10-J. Speed signs to left of track:

Eastward	Reading	Westward	Reading
MP 513.05	40	MP 539.07	25 Diverging Route
MP 514.80		MP 540.75	30
MP 539.77	30	MP 585.75	45
MP 562.55	25	MP 599.25	60
MP 575.83	45—25		
MP 617.66	60		
MP 618.50	70—60		
MP 733.01	60		

RULE 26-A. Colton. Indicator lights located at each end of icing platform on PFE Tracks Nos. 28, 30 and 36, and at switch to 38 spur, govern movement on those tracks as follows:

- Green:** Tracks may be used for train or switching movements.
- Red:** Tracks may be entered but cars on tracks must not be coupled to or moved. Trains made up on these tracks must not depart until it has been ascertained indicator displays green aspect.
- Not lighted:** Must be considered as displaying most restrictive indication and icing platform foreman must be contacted for instructions before cars are coupled to or moved.

Yuma: Indicator lights located above Tracks Nos. 8 and 9 at each end PFE icing platform govern movements on those tracks as follows:

- Green:** Tracks may be used for train or switching movements.
- Yellow:** Tracks may be entered, switched, and engines, cars or cabooses added or detached.
- Red:** Tracks may be entered but cars on tracks must not be coupled to or moved. Trains made up on these tracks must not depart until it has been ascertained indicator displays green aspect.
- Not Lighted:** Must be considered as displaying most restrictive indication and icing platform foreman must be contacted for instructions before cars are coupled to or moved.

RULE 82-A. First-class trains and trains consisting of passenger equipment only, authorized on Colton Subdivision and operating through Indio Yard with same conductor and engineer are thereby authorized without obtaining a clearance at Indio Yard.

RULE 83. Extra trains or engines operating in below listed territories must register destination of trip (turning point), and date and time of departure in column captioned "Signals." When trip has been completed, date and time of arrival at initial station of trip must also be entered in column captioned "Signals." Engines en route into these territories must not leave the initial station until it has been ascertained from the train register that all preceding engines via the route to be used have completed their trips and registered time and date of arrival at initial station of trip accordingly:—

Territory **Register Location**

Baldwin Park Branch:	
Baldwin Park-State Street (Los Angeles) . . .	Baldwin Park
Bench-San Dimas	Colton
Azusa Branch:	
Orange Ave. Jct.-Azusa	Orange Ave. Jct.
Chino Branch:	
Pomona-Chino	Pomona
Riverside Branch:	
Colton MP 541.2-Corona	Colton
Redlands Branch:	
Bryn Mawr-Redlands	Colton
Calexico Branch:	
Heber-Calexico	El Centro
Westmoreland Branch:	
Calipatria-Westmoreland	Calipatria
Sandia Branch:	
Holtville-End of Branch	Holtville

RULE 83-A. At the following stations only trains indicated will register:
 Colton Trains originating and terminating and trains via Hiland
 Indio Yard Trains originating and terminating

RULE 83-B. At open train-order offices, trains may register by ticket as follows:
 Colton Trains via Hiland

RULE 93. Yard limits in which the provisions of Rule 93 will apply, except within CTC limits, are established at the following points:

West MP	East MP
	Palmdale 419.07
471.20	Los Angeles (Burbank Jct. to Alhambra) 488.69
511.57	City of Industry (both legs of wye) 512.67
514.30	Pomona (Chino Branch) End of Branch
536.51	Colton 541.14
539.00	Colton (Riverside Branch) End of Branch
544.57	Bryn Mawr (Redlands Branch) End of Branch
539.00	Colton (San Bernardino Branch) End of Branch
607.85	Indio 618.41
731.51	Yuma 737.83
	Yuma (Yuma Valley Railroad) End of Branch
674.52	Calipatria (Calexico Branch) End of Branch
674.52	Calipatria (Westmoreland Branch) End of Branch
	End of Branch (Sandia Branch) 713.7
	2.00 State Street (Baldwin Park Branch) 7.50
	7.50 Baldwin Park Branch 23.00
	25.00 Baldwin Park Branch Bench 56.11
	18.04 (Bassett Branch) End of Branch
	18.08 (Orange Ave. Jct.-Azusa Branch) End of Branch

Colton: Movements between CTC limits (MP 538.70 and MP 540.05) will be governed by block signal indication which will supercede the superiority of trains.

Indio. Eastward Freight trains before passing Jackson Street Overpass, must contact yardmaster or his representative for instructions unless proceed signal is received or engineer is orally authorized.

Yuma: Trains must not enter or depart Yuma Yard unless a proceed signal is received, green flag by day, green light by night, or engineer is orally authorized.

RULE D-97. Applies between Los Angeles and Alhambra, and between MP 609.74, Indio and MP 618.41, Thermal, and between end of CTC, MP 732.45, Yuma, and Subway, MP 734.26.

RULE 98. Trains and engines must approach with caution, and may move over following crossings without stopping, if crossing clear and no movement approaching on intersecting line:

- *Upland—AT&SFRy—MP 37
- *Grapeland—AT&SFRy—MP 42
- *Rialto—AT&SFRy—MP 52

*Must not exceed 15 MPH.

Stop clear of following crossings and send flagman ahead, who must ascertain that no movement approaching on intersecting line before giving signal to proceed:

- San Bernardino—"E" St.—AT&SFRy—MP 57
- Porphyry—AT&SFRy—1.54 mile west of Corona

RULE 103 A. Automatic crossing gates:

Following crossings protected by gates with control circuits located within short distance of crossings.

Station	Location	MP
*Pomona.....	Park Ave.....	514.10
*Pomona.....	Main St.....	514.30

*Sound detector microphone located just east of Park Avenue crossing, MP 514.10, identified by marker block reading "STOP" located north of main track. Westward trains making station stop on main track only to receive or discharge passengers must sound whistle for one second which will activate the crossing gates.

Riverside: Crossing bells located at Seventh and Ninth Streets are manually controlled with switches located on the bells.

Public Utilities Commission orders require that trains and engines must stop, and member of crew protect traffic on the following street or highway crossings before movement is made:

- Redlands 2nd St.—Over Orange St.
- Redlands 2nd St.—Over Fourth St.
- Indio—Over highway on California Date Growers Assn. spur.

El Centro—Over Commercial Ave. and Second Ave. on No. 70 drill.

Azusa—Over Todd Ave. on Marmion Lumber Co. spur. Lighted fuses must be placed on each side of track before entering crossing. Movements are confined to daylight hours.

Trains must stop and traffic on highway be protected by member of the train crew over the following crossings:

- Brawley—When shoving cars eastward over K. St. on Even drill or Standard Oil Spur. When engine ahead, stop, sound whistle signal 14(l) and if crossing clear, proceed.

El Centro—Before pushing or backing cars on house track or drill track over Main Street.

Imperial: Before pushing or backing cars over Main Street on Spur track serving Arical Company.

RULE 104. The normal position of rigid switches at junction points is as follows:

- City of Industry.. Puente Branch, for connecting track.
- Colton..... Junction switch on Riverside Br., for main track.
- Riverside Jct.... Junction switch for main track.
- Baldwin Park... For Bassett Branch.
- Orange Ave. Jct.. For Azusa Branch.
- Ferrum..... EMRR for Interchange track.
- Calipatria..... Westmorland Br., for Calexico Branch.
- Holtville..... Holton Interurban main track for Sandia Branch.
- El Centro..... Interchange track, for SD&AERy main track.
- El Centro..... Sandia Branch, for east leg of old wye.

DERAILS IN MAIN TRACK:

- Bryn Mawr..... Redlands Branch.

City of Industry: Normal alignment of switch at east leg of wye is to extension track.

Cars must not be left on either the east or west leg of wye track or connecting track to UPRR.

City of Industry: One rigid and four variable switches at City of Industry Yard have been equipped with black plate bearing a white letter "N" mounted above switch target. These switches must be returned to normal position after each use and must not be left open for another train or engine unless a member of crew is left in charge. Normal position of these switches will be with the switch target parallel to track.

RULE 105. Thermal: Eastward siding extends between eastward absolute signal, MP 618.41, beginning of CTC and westward absolute signal at spring switch, MP 620.15.

Westward trains must not use this siding without obtaining permission from train dispatcher.

RULE 201. Baldwin Park Branch: Trains and engines must not operate between MP 23.00 and MP 25.00 without train order authority.

RULE 211. Palmdale: To enable Train Dispatcher to advance a westward train from the Colton Subdivision beyond junction switch, operator after receiving verbal authority from Train Dispatcher will clear westward interlocking signal governing movement to Mojave Subdivision for movement on main track which will be an indication to an approaching train that train orders have been issued authorizing movement to the next station at least, against and ahead of all superior trains, and will not require the issuance of Form "N" train order or the lowering of train order signal arm several times.

RULE 221. Colton is train-order office for trains originating and westward trains via Hiland only.

El Centro is a train-order office for SD&AE trains and trains originating via Iris or Wister.

RULE D-251. Will apply as follows:

- Both tracks between Los Angeles and Alhambra.
- Both tracks between MP 609.74, Indio and MP 618.41, Thermal.
- Both tracks between end of CTC, MP 732.45, Yuma and Subway, MP 734.26.

RULE 286. When distant signals governing movements on sidings display yellow aspect, train may proceed on siding at restricted speed expecting to find siding occupied by a preceding train.

RULE 306. The following block signals equipped with triangular plate bearing the letter "P" have included in their control limits some special protective device. Interlocking signals are listed as "P-I." Absolute signals are listed as "P-A."

Eastward Signal	Protection	Westward Signal
4912	Dragging equipment detector, MP 488.5 absolute signal at MP 485.73.	
	Two indication light type indicators installed adjacent to eastward automatic Signal 4912, MP 491.20, San Gabriel Blvd., San Gabriel, and to the right of westward main track and to the left of eastward main track 550 feet east of Valley Blvd., MP 485.91, and designed as dragging equipment indicators.	
	Indicators will display red aspect when actuated by dragging equipment detector and lunar aspect when not actuated by dragging equipment detector.	
	Crew of train stopped by red indicator will inspect their train for dragging equipment and then call dispatcher who will change indicator aspect from red to lunar.	

Eastward Signal	Protection	Westward Signal
P-4960	Barricade Detector MP 496.3	P-4963
	Spring Switch east end Palmdale Siding No. 2	P-4181
P-4904	Spring Switch at MP 490.37	
P-A	High water detector, Bridge MP 550.41	P-5511
P-A	High water detector, Bridge MP 583.26	P-5839
P-A	High water detector, Bridge MP 583.33	P-5839
P-6086	High water detector, Bridge MP 608.93	Absolute Signals MP 609.72
P-A	High water detector, Bridge MP 618.60	P-A
P-A		
P-A	Spring switch, east end eastward siding, Thermal	
P-A	Movements over end of derailling spur, Ferrum, MP 638.9	P-A
P-A	High water detector bridge, MP 640.87	P-6417
P-A		
P-6510	High water detector bridge, MP 651.99	P-6531
P-6708	High water detector bridge, MP 672.79	P-6729
P-A	High water detector bridge, MP 691.62	P-6919
P-A		
P-A	High water detector bridge, MP 705.26	P-A
P-A	High water detector bridge, MP 713.28	P-A
P-A	Spring switch, east end Colorado River bridge, Yuma	P-A
P-A		
	Spring switch, MP 737.50, east end crossover from running track to Track No. 2	P-SA

RULE 505. AUTOMATIC BLOCK SIGNAL SYSTEM

Taylor Jct.: When signal 4841 displays stop indication trains and engines after stopping must contact signal operator at Mission Tower and be governed by his instructions.

Indio Yard: Signal 6130 on yard lead track governs movements through crossover between yard lead and Main tracks to Eastward track with current of traffic only.

Signals 6111 and 6113 on No. 1 drill track govern movements through crossover to Westward track only.

Yuma: Main tracks between MP 734.26 and MP 737.50 are designated as follows:

- No. 1 Track—To north.
- No. 2 Track—To south.

Between MP 734.26 and MP 737.50 trains or engines may use main tracks in either direction, being governed by signal indication.

Signal 7333 governs westward movements through crossover to main tracks only and will remain dark until crossover switch is open.

Westward signal adjacent to Track No. 2, MP 734.32, will display red aspect only as per Rule 290, fig. I. Trains and engines will be governed by yardmaster's instructions before passing this signal.

These signals will remain dark until crossover switches are open.

RULE 535. SPRING SWITCHES

Pomona. Junction switch Chino Branch on siding at Pomona is equipped with switch point indicator. If red aspect is displayed or indicator light is extinguished careful examination of switch must be made before making a facing point movement.

Yuma: Spring switch on engine lead equipped with switch-point indicator. Indicator does not indicate track occupancy. Indicator will display green aspect with switch in either normal or reverse position. When indicator displays red aspect or indicator light is extinguished, careful examination of switch must be made before making a facing point movement.

RULE 538. Spring switches not equipped with facing point locks are located as follows:

Location	Normal Position
Pomona Junction, Chino Branch	Controlled siding
*Yuma West leg of wye from running track	West leg of wye
	East leg of wye from running track
	Running track
	Tail end of wye
	West leg of wye
	East end Roundhouse Track No. 1
	East leg of wye
	West end Roundhouse Track No. 1
	Roundhouse Track No. 1

*All engines to diesel facilities will use west leg of wye into roundhouse service track.

Spring switches equipped with facing point locks are located as follows:

Location	Normal Position
Slover	West end siding at MP 490.37
	Main Track
Palmdale No. 2	East end siding No. 2
	Main Track
Thermal	East end eastward siding
	Main Track
Yuma	East end bridge
	Eastward Track
East Yard	East end of crossover from running track to Track No. 2
	Track No. 2

RULE 605. INTERLOCKING

Mission Tower: Limits extend on both tracks of East Bank line from interlocking signals located 300 feet west of East Bank Jct. switches to westward interlocking signals located on Signal Bridge No. 2; on both tracks of River Station line to interlocking signals located 250 feet west of Naud Jct. switch; on Colton Subdivision on Westward Track to interlocking signal located 300 feet east of Taylor Jct. and on Eastward Track from switches at MP 482.85 to interlocking signals located 400 feet east of Taylor Jct.

Colton Tower: Limits extend eastward on main track and siding from MP 538.60, to westward interlocking signals just east of AT&SF Ry. crossing, MP 538.68.

Palmdale: Limits extend from junction switch MP 414.42 to MP 416.62.

RULE 663(b). Mission Tower: Signal just west of tower building and adjacent to track No. 55 has white disk attached to mast. Signal is to right of two converging tracks, and governs movement on either track.

Following addition to Rule 663 (b) applies at Mission Tower, "Upon receiving oral authority of operator or signal maintainer."

RULE 669. Mission Tower: One long sound of tower air whistle requires all movements through plant to stop immediately and remain standing until authorized by operator to resume movement.

RULE 680. AUTOMATIC INTERLOCKING

Limits extend between interlocking signals both sides of crossings:

Baldwin Park Branch, ATSF Crossings:

- San Dimas
- North San Dimas
- Euclid
- Claremont

Riverside Branch:

MP 544 Riverside ATSF Crossings

Following instructions to govern use of these crossings:

Switch indicator and derail are located on each side of ATSF Railway tracks. Each derail is a spring derail that can be trailed through. A signal is located at facing point of each derail. When crossing the ATSF Ry and switch indicator shows clear, remove lock. In 50 seconds electric lock will release, then line derail and the signal will clear.

When switch indicator is at stop, trainmen, after removing lock from derail must ascertain that no movements are approaching, then place ATSF Railway signal at stop by inserting key in circuit controller at crossing and holding for 10 seconds. After 5 minutes signal will clear. If signal does not clear call ATSF Railway dispatcher. Key must not be inserted if movement is approaching, however, if it is apparent that the approaching movement will not continue over the crossing proceed as described when switch indicator is at stop.

The electric lock is equipped with two treadles. Depress upper treadle ONLY to remove lock. Depress lower treadle to unlock operating lever on derail.

RULE 705. HOT BOX DETECTORS

Illum. Letter	On Signal	Approach- ing	Location of Readout
H*	M.P. 525.1	Guasti	Westward Absolute Signal W.E. Guasti
W	5258	So. Fontana	
W	5281	Guasti	
H	5282	So. Fontana	Eastward Absolute Signal E.E. South Fontana
H		Westward Absolute Signal E.E. Palm Springs	Westward Absolute Signal W.E. Palm Springs
H*	M.P. 586.12	ML East end	Eastward Absolute
H*	M.P. 586.12	Siding Garnet	Signal M.P. 587.8 Garnet
H		Westward Absolute Signal E.E. Ferrum	Westward Absolute Signal W.E. Ferrum
W	6434	Bertram	
W	6447	Ferrum	
H		Eastward Absolute Signal W.E. Bertram	Eastward Absolute Signal E.E. Bertram
H		Westward Absolute Signal E.E. Niland	Westward Absolute Signal W.E. Niland
W	6694	Iris	
W	6709	Niland	
H		Eastward Absolute Signal W.E. Iris	Eastward Absolute Signal E.E. Iris

*Displays flashing white light when "H" illuminated.

SCANNER SITE

M.P.	Direction	Location
526.6	East and West	Guasti-South Fontana
584.5	East and West	West Palm Springs-Garnet
643.8	East and West	Ferrum-Bertram
670.5	East and West	Niland-Iris
**431.1	East and West	Palmdale-Wash
**457.9	East and West	Phelan-Hivolt

Refer to Rule 705, All Subdivisions

**Be governed by the following in lieu of paragraphs 1 through 7, Rule 705, All Subdivisions:

Detector instrument house is equipped with indicator array consisting of white lights and revolving red beacon.

White light at top center of indicator array will be continuously displayed except when a hot bearing has been detected at which time light will start flashing. Absence of white light must be promptly reported to train dispatcher.

Revolving red beacon at top center of indicator array will be normally dark except when a hot bearing has been detected, beacon will be actuated.

Three vertical white lights are located on each side of indicator array. Lights on right side will be displayed for hot bearings on right side of train, and lights on left side will indicate hot bearings on left side of train, in direction of movement. Top light indicates first hot bearing, second light indicates second hot bearing, and third light indicates third hot bearing. Lights will indicate a maximum of three hot bearings on each train.

Crew members must keep vigilant look-out when passing these locations, and if hot bearing is detected, train will be stopped promptly, and inspection made to locate car with hot bearing. In addition, truck of car with hot bearing will be sprayed with fluorescent dye marker for identification. All journals on car marked, as well as car ahead, must be inspected.

When indicator array indicates hot bearing on train, and no dye marker is observed, all journals of train must be inspected.

RULE 760. CENTRALIZED TRAFFIC CONTROL

Limits extend on westward track from MP 482.90 and on eastward track from MP 485.55 to end of double track MP 488.22. From end of double track MP 488.22 to Colton Tower MP 538.70. From Bench MP 489.68 to West Colton MP 538.40 and Colton Tower MP 538.70. From Colton MP 540.05 to Indio MP 609.74. From Thermal MP 618.41 to Yuma MP 732.38.

Calxico Branch: Limits extend from Yard track between crossover switch west of station and both legs of Wye track, Niland to Calipatria MP 675.01.

Baldwin Park Branch: Limits extend between absolute signals each side of main track crossing El Monte and from absolute signal to junction switch, Bench.

Aurant: At MP 482.90, East End. That portion of drill track 10 feet west of initial switch of crossover from drill track to westward track is also in CTC limits.

Westward track signaled for movements in both directions between MP 482.90 and end of double track 488.22. Eastward track signaled for movements in both directions MP 485.55 and end of double track MP 488.22.

Main tracks between West End Ordway and East End Beaumont, and between Araz Junction and Yuma are numbered as follows:

- No. 1 Track—to north
- No. 2 Track—to south

Block signals are provided for movement of trains in either direction on both main tracks.

RULE 765. Except when moving on signal indication, yard engines must not occupy westward main track between "A" signal just west of Valley Boulevard MP 485.22 and Taylor Junction for switching movements without authority from train dispatcher. This authority may be obtained from dispatcher by Shops Yardmaster and must be furnished by him to yard crews when performing switching. When switching is completed and yard engine clear of westward main track, yard crews must notify Shops Yardmaster immediately who will release track back to train dispatcher.

RULE 776. El Monte: Movements across Baldwin Park Branch are under control of train dispatcher. When absolute signals governing movements over crossing display stop indication, member of crew must call train dispatcher, and after ascertaining that derails in both directions are set to derail, and no train is approaching from either direction, train dispatcher may authorize movement over crossing.

Movements on Baldwin Park Branch are also under control of train dispatcher. When absolute signals governing movement across main track display stop indication, member of crew must call train dispatcher, and after ascertaining that derails are lined for movement, and no trains are approaching from either direction, train dispatcher may authorize movement over crossing.

Ontario: Movements across UPRR track on spur governed by dwarf type light signals. Electrically locked derails 200 feet either side of UPRR main track are controlled by UPRR train dispatcher. If electric lock fails to unlock within three minutes contact UPRR train dispatcher by telephone and be governed by his instructions. Telephone in box at crossing.

Pomona: Movements across UPRR main track on Chino Branch, under control UPRR train dispatcher. Eastward trains to Chino Branch must line initial switch before signal will clear. Westward signal will clear on approach of train. If these signals fail to clear, contact UPRR train dispatcher by telephone and be governed by his instruction. Telephone in box at initial switch and in UPRR CTC house at crossing.

Call-on unit, near junction switch, when flashing white will authorize trains and engines from Chino Branch to enter controlled siding at Pomona, expecting to find siding occupied.

GENERAL REGULATIONS

RULE 825. Portable rail skids are hung on posts at following locations:

Pomona—west end	Slover—east end
Redlands—west end	Dike—east end
Ordway—west end	Canyon—east end
Pershing—east end	Hiland—east end
Banning—east end	Wash—west end
Garnet—east end	Palmdale Siding
Salvia—east end	No. 2—west end
Rimlon—east end	

Rail skid must be placed on rail and leading wheel of first car in descending direction run onto the rail skid, and hand brakes set if brakes are operative, before engine is detached. Trains picking up cars from these sidings must remove rail skid and return it to proper post and lock it in place with switch lock.

City of Industry: Not less than ten hand brakes must be set on west end of A or C Yard when cars are left standing, except when less than ten cars all hand brakes must be set. When necessary to release hand brakes to move a portion of the cars the same number of brakes must be set on remaining cars. Conductors will be held responsible for compliance with the above.

Irwindale: 6 hand brakes must be set on lower end. When less than 6 cars all hand brakes must be set.

At any location where number of hand brakes are specified and it is necessary to release hand brakes to move a portion of the cars the same number of brakes must be set on remaining cars.

Pomona: Hazel Atlas Glass Company tracks have rail skids to prevent cars from rolling out. Crews must remove clamps before switching these tracks, and replace after switching.

Yuma: Freight trains.....Four brakes on east end.
Two brakes on west end.

East Yard: Freight trains...Two brakes on east end.
Five brakes on west end.

RULE 837. Switching movements must be made with air brakes cut in on all cars and cars must not be detached while in motion except when allowing caboose to roll against train on descending grade, at following locations:

Lincoln Park Spur—Baldwin Park Branch
MP 420 Palmdale to 491.9 Colton
Redlands Branch
Loma Linda to Garnet

RULE 883. Light engines must not be left unattended between Colton and Indio or Hiland and Colton unless protected by derail or inside switch.

AIR BRAKE RULES

FREIGHT TRAINS

RULE 17. Be governed by the following:
Retaining valves will be used on descending grades as follows:

Passenger Trains

Beaumont to Colton, Beaumont to Garnet, Hiland to Colton.

All retaining valves will be used except when three or more units of dynamic brakes are in operation.

Freight Trains

Retaining valves must be used on freight and mixed trains, excluding ore trains, on descending grades as follows:

Beaumont to Colton
Beaumont to Garnet
Hiland to Colton

Without Dynamic Brake in Operation:

One retaining valve for each 80 tons in trains. If gross tonnage exceeds 80 tons per operative brake retaining valves must be used on all cars and speed must not exceed 15 MPH.

With Dynamic Brake in Operation:

Permissible Tons per Unit without Retaining Valves*

	Basic Dynamic Brake		Extended Range Dynamic Brake		
	4-Axle	6-Axle	4-Axle	6-Axle	8-Axle
With dynamic brake in operation WITH-OUT pressure maintaining system of braking.....	525	775	625	950	1250
With dynamic brake in operation WITH pressure maintaining system of braking...	1500	2250	1800	2700	3600

If permissible tonnage is exceeded, one retaining valve must be used for each 150 tons of excess tonnage.

*If any unit having basic dynamic brake is operated with units having extended range dynamic brake, all units in consist must use tonnage authorized for units having basic dynamic brake.

Locomotive classes AF 628, AF 630, EF 425, EF 623, EF 625, EF 630, EF 636, GF 425, (except units 6700-6727), GF 628, GF 630, GF 633, EF 850B, and GF 850 are equipped with extended range dynamic brake.

ORE TRAINS

Ore trains consisting of cars equipped with ABEL (empty and load) brake system as shown under Rule 23, All Subdivisions, Beaumont to Loma Linda or Colton:

No. of Axles of Dynamic Brake in Operation in Train	No. of Retaining Valves Required
0—12	100%
12—23	75%
24—41	50%
42 or more	None

RULE 17A. Freight trains without dynamic brake in operation using retaining valves will stop at the following stations for at least ten minutes to permit wheel heat radiation.

EASTWARD

Between Owl and Cabazon MP 474.00 east of Canyon

WESTWARD

Between MP 553.00 and Ordway

RULE 24-B. Palmdale, Indio and Yuma: Incoming engineer, after completing stop, must make a full service brake application leaving brakes applied. When outgoing crew takes charge of train on arrival or otherwise is assured, upon request, that continuity of brake pipe has not been disturbed, engineer will release brakes and proceed.

RULE 25. Will apply at Beaumont to trains in both directions and at Hiland to eastward trains, except trains not using retaining valves and not required to stop. Trains not required to stop must make running test approaching MP 563.00, Beaumont, and between MP 455 and Hiland as follows:

Engineer while working power will make reduction of approximately 7 lbs., wait for slack to adjust, then make a 3 lb. reduction before releasing brakes. Trainmen will give proceed signal after noting reduction in brake pipe air pressure and knowing that the air pressure is being properly restored, as indicated by caboose gauge, and that brakes on caboose have been released. On ore trains this test must be made and brakes released before reaching MP 563.5.

RULE 33. Hiland to Colton, Redlands Branch, Beaumont to Garnet.

Maximum tonnage per operative brake..... 80 tons
 Except with dynamic brake and pressure maintaining system of braking in operation with not more than 100 cars and speed not exceeding 20 MPH 100 tons

Ore trains consisting of cars equipped with AB empty and load brake system as shown under Rule 23, All Subdivisions 139½ tons

If retaining valves not required as prescribed by Air Brake Rule 17, must not exceed 25 MPH.

Without dynamic brake in operation while handling in excess of 80 tons per operative brake, train may proceed not exceeding 15 MPH if in judgment of conductor and engineer it is safe to do so, provided retaining valves are used as prescribed by Air Brake Rule 17.

Restrictive grades are as follows:

EASTWARD

(Station) MP	to	(Station) MP	Speed
563		589	
Beaumont		Garnet	20
463.9		492.7	
Hiland		Colton	20

WESTARD

(Station) MP	to	(Station) MP	Speed
563		541	
Beaumont		Loma Linda	20

PASSENGER TRAINS

RULE 39. Running test must be made before descending grade, Beaumont, and eastward trains at Hiland.

TRAIN HANDLING

RULE 60. When operating over either leg of wye between east switch Slover and West Colton, dynamic braking force must not exceed one-half of maximum.

MISCELLANEOUS

1. Kaiser. Lead track from north line of Colton Ave., jointly used by SP and Kaiser Co.; the tracks within Kaiser plant jointly used by SP, AT&SFRy, and Kaiser Co., and nine tracks within Kaiser plant jointly used by SP and Kaiser Co. SP crews must not go beyond a point 250 feet east of easterly lead switch (connection with AT&SFRy.) in "X" yard, or 200 feet east of crossover 222 at ore dump. All movements must be made with caution. Derails must be left in derailing position while switching at Kaiser plant, and secured in derailing position when leaving plant. Hand brakes must be secured on at least four cars on lower end when setting out on Kaiser plant tracks. When picking up cars at least four hand brakes must be secured on lower end of cut remaining in the track. If four cars or less, secure all hand brakes. Air must be coupled and in use through entire cut of cars when moving to or from Kaiser plant, and air brake test must be made as prescribed in Air Brake Rule 24-F.

Before coupling air hose on cars within Kaiser plant, engine must be placed against cars on track to be picked up and member of crew must be stationed at east switch, or switch to rear of cut, to prevent Kaiser or AT&SF Railway crews from switching or dropping cars against cut being handled by SP crews.

2. Dragging and/or derailed equipment detector and indicator installed at the following locations:

MP	Location
678	Between Iris and Regina
715	Between Cactus and Ogilby

Indicator mounted on post adjacent to detector will display revolving red light when detector is actuated. Crew members must keep vigilant look out when passing these locations, and if revolving red light observed, train will be stopped promptly, and inspection made of train and track, notifying dispatcher of condition found. Revolving red light will be automatically extinguished when track circuit is cleared.

3. Train dispatching between Yuma and East Yard is under the jurisdiction of Tucson Division.

4. Southern Pacific employes using UPRR or ATSF railroad tracks will have in their possession while on duty copy of current booklet containing information pertaining to Operating Rules of these railroads.

5. Load Limit (Car & Contents):

**Los Angeles—Yuma	263,000 pounds
*Ferrum—City of Industry	279,000 pounds
Chino Branch	251,000 pounds
Riverside Branch	240,000 pounds
Redlands Branch	230,000 pounds
Baldwin Park Branch	196,000 pounds
Bassett Branch	199,000 pounds
San Bernardino Branch	156,000 pounds
Calexico Branch	251,000 pounds
Westmorland Branch	240,000 pounds
Sandia Branch	240,000 pounds

*Ore when consisting of cars in Series SP 345000 to SP 345669 and SP 463500 to SP 463999.

**Gross weight of 315,000 pounds applies to uniformly loaded four-axle cars with minimum axle spacing of 6 ft. 0 in. and minimum distance 37 ft. 0 in. between truck centers; also, with wheels 38 inches or more in diameter.

Between Niland and Calexico gross weight of 281,000 pounds applies to uniformly loaded four-axle cars with minimum axle spacing of 6 feet 0 inches and minimum distance of 37 feet 0 inches center to center of trucks; also, wheels 38 inches or more in diameter. Movement of cars thus loaded allowed on entire Calexico Branch except siding structures at MP 686.80 and MP 687.34.

Unless authorized by Superintendent, heavier loads will not be handled.

SPECIAL INSTRUCTIONS—COLTON SUBDIVISION

6.

LOCATION OF OVERHEAD AND SIDE STRUCTURES NOT STANDARD CLEARANCE ON MAIN TRACK AND SIDINGS

MP	Location	Description
482.60	Los Angeles 2nd crossing L.A. River	bridge Overhead and Side
539.80	Colton Santa Ana River bridge	Side
547.30	West of Redlands, 2nd Street Mill Creek bridge	Overhead and Side
607.57	Myoma overhead crossing	Overhead
732.30	West of Yuma Colorado River bridge	Side
1.96	Macy St., (Brooklyn Ave.)	Overhead
2.75	State Street	Side
3.10	Cornwall St.	Overhead and Side
3.29	Soto St.	Side
61.22	Santa Ana River Bridge (Marigold)	Overhead and Side
	Arlington to Porphyry	Overhead and Side

7.

SPEED RESTRICTIONS FOR OTHER THAN MAIN TRACKS

With Caution
Not Exceeding
MPH

Through sidings, yard and other tracks, wyes, crossovers, turnouts and slip switches	10
Controlled sidings, turnouts and crossovers	25
Except:	
Crossover MP 541.35	
Beaumont MP 562.2 crossover	
Pershing	
Cabazon west switch siding MP 571.2	20
Colton to Palmdale	
Through sidings and turnouts	25
Indio to Yuma	
Turnouts and crossovers	25
Through sidings	30
Except MP 729 crossover	35
*Yuma—over, upon or across any street cross- ing	5

*Regulated by City Ordinance

SPECIAL INSTRUCTIONS—COLTON SUBDIVISION

SPEED RESTRICTIONS FOR TRAINS: Maximum speed of trains in territory shown below is subject to further restrictions applicable to engines in the train as shown in **SPEED RESTRICTIONS FOR ENGINES** appearing on page 4, and **MAXIMUM SPEED PERMITTED WITH CERTAIN EQUIPMENT** and **OTHER MAXIMUM SPEEDS** appearing on pages 3 and 4 of Special Instructions for All Subdivisions. Speed must be further reduced as prescribed by speed signs, except as specifically authorized by Special Instructions herein, or by timetable bulletin.

All trains must run carefully during and after heavy storms, particularly when the track is apt to be affected. When fog, storms or other conditions obscure track or signals, speed of trains must be so reduced as to permit strict observance of signals and **INSURE SAFETY, REGARDLESS OF TIME.**

TERRITORY			PASSENGER TRAINS	FREIGHT AND MIXED	TERRITORY			PASSENGER TRAINS	FREIGHT AND MIXED
MP	MP	Column:	1	2	MP	MP	Column:	1	2
EASTWARD LOS ANGELES YARD TO TAYLOR JCT.:					WESTWARD YUMA TO LOS ANGELES:				
478.50 to 480.60 (Dayton Ave. Tower)			40	40	737.83 to 737.50			70	60
480.60 to 481.67			20	20	737.51 to 737.50 (Through Crossover)			35	35
481.67 to 481.69 (North Main St.)			15	15	737.50 to 734.50 (Track No. One)			60	60
481.69 to 481.90 (East Bank Jct.)			20	20	734.50 to 733.01 (Track No. 1 and No. 2)			20	20
481.90 to 482.80 (Taylor Jct.)			15	15	733.01 to 732.10 (Through Turnouts)			15	15
EASTWARD LOS ANGELES TO YUMA:					WESTWARD YUMA TO LOS ANGELES:				
Los Angeles to Mission Tower			12	12	732.10 to 727.00, except			70	60
Mission Tower to 484.05			15	15	729.20 to 728.80 (Through Turnout)			35	35
484.05 to 485.80 (Valley Blvd.)			25	25	727.00 to 723.06			50	50
485.80 to 488.22 (Alhambra)			40	40	723.06 to 618.50			70	60
488.22 to 488.23 (End Double Track)			35	35	618.50 to 618.41			60	60
488.23 to 489.89 (Alhambra)			40	40	618.41 to 612.67			70	60
489.89 to 491.33 (San Gabriel)			30	30	612.67 to 610.80			30	30
491.33 to 493.31			65	60	610.80 to 598.50			70	60
493.31 to 495.04 (El Monte)			40	40	598.50 to 589.00			60	60
495.04 to 513.80			65	60	589.00 to 585.00			55	55
513.80 to 514.80 (Pomona)			40	40	585.00 to 576.58			45	45
514.80 to 519.51			65	60	576.58 to 563.35			50	50
519.51 to 520.91			40	40	563.35 to 563.30 (Through Turnout)			25	25
520.91 to 523.40			65	60	563.35 to 554.82 (Track No. One)			50	25
523.40 to 537.32			70	60	554.82 to 548.24 (Track No. One)			45	25
537.32 to 538.52			50	50	548.24 to 548.20 (Track No. One)			25	25
538.52 to 540.00			30	30	563.30 to 554.82 (Track No. Two)			50	25
540.00 to 545.28			60	60	554.82 to 548.20 (Track No. Two)			45	25
545.28 to 548.20			50	50	548.20 to 545.28 (Track No. Two)			50	25
548.20 to 548.24 (Track No. One)			25	25	545.28 to 540.00			60	25
548.24 to 554.82 (Track No. One)			45	45	540.00 to 538.52			30	30
554.82 to 563.35 (Track No. One)			50	50	538.52 to 537.32			50	50
548.20 to 554.82 (Track No. Two)			45	45	537.32 to 523.40			70	60
554.82 to 563.30 (Track No. Two)			50	50	523.40 to 520.91			65	60
563.30 to 563.35 (Track No. Two)			25	25	520.91 to 519.51			40	40
563.35 to 576.58			50	25	519.51 to 515.55			65	60
576.58 to 585.00			45	25	515.55 to 514.80			65	55
585.00 to 589.00			55	25	514.80 to 513.80 (Pomona)			40	40
589.00 to 599.00			60	40	513.80 to 507.80			65	50
599.00 to 608.85			70	60	507.80 to 495.04			65	60
608.85 to 609.60			70	50	495.04 to 493.31 (El Monte)			40	40
609.60 to 612.67			30	30	493.31 to 491.33			65	60
612.67 to 618.41			70	60	491.33 to 489.89 (San Gabriel)			30	30
618.41 to 618.50 (Through Turnout)			60	60	489.89 to 485.80 (Alhambra)			40	40
618.50 to 723.06			70	60	488.23 to 488.22 (Through Turnout)			35	35
723.06 to 727.00			50	50	485.80 to 484.05 (Valley Blvd.)			20	20
727.00 to 731.35 except			60	60	484.05 to Mission Tower			15	15
728.80 to 729.20 (Through Crossover)			35	35	Mission Tower to Los Angeles			12	12
731.35 to 732.10			60	45	WESTWARD, TAYLOR JCT. TO LOS ANGELES YARD:				
732.10 to 733.01 (Through Turnout)			15	15	482.80 to 481.90 (Taylor Jct.)			15	15
733.01 to 736.78 (Track No. Two)			60	60	481.90 to 481.69 (East Bank Jct.)			20	20
736.78 to 737.50 (Track No. Two)			60	55	481.69 to 481.67 (North Main St.)			15	15
737.50 to 737.51 (Through Turnout)			35	35	481.67 to 480.00			20	20
737.51 to 737.83			70	60	480.00 to 478.50 (L.A. Yard)			40	40

EASTWARD PALMDALE TO WEST COLTON:

414.4 to 414.6	35
414.6 to 463.8	49
463.8 to 487.0	30
487.0 to 491.9	40
491.9 to 492.7	25
West leg of wye, West Colton	15

WESTWARD WEST COLTON TO PALMDALE:

West leg of wye, West Colton	15
492.7 to 491.9	25
491.9 to 487.0	40
487.0 to 463.8	30
463.8 to 414.6	49
414.6 to 414.4	35

Eastward trains in excess of 300 tons per axle of dynamic brake in operation must not exceed 25MPH between Hiland MP464 and MP 487.

Kaiser (Kaiser Spur): MP 529.1. Do not exceed 10 MPH over switch at San Bernardino Street.

Freight and mixed trains are authorized to operate at Column 1 speeds not to exceed 65 MPH between Alhambra and Yuma (BSM—70 MPH) when meeting requirements, as outlined on page 5, except must not exceed 40 MPH on descending grades between Colton and Garnet.

Trains with class of engine shown below are further restricted between points shown, as follows:

BS-412, ES-410, FS-412, AS-410	20
EF-418, EP-418	25
AS-418	20
EF-415, EP-415	25

SANDIA BRANCH	
MP 691.04 and MP 697.70	
	20
	25
	20
	25

SPECIAL INSTRUCTIONS—COLTON SUBDIVISION

SPEED RESTRICTIONS FOR TRAINS: Maximum speed of trains in territory shown below is subject to further restrictions applicable to engines in the train as shown in **SPEED RESTRICTIONS FOR ENGINES** appearing on page 4, and **MAXIMUM SPEED PERMITTED WITH CERTAIN EQUIPMENT** and **OTHER MAXIMUM SPEEDS** appearing on pages 3 and 4 of Special Instructions for All Subdivisions. Speed must be further reduced as prescribed by speed signs, except as specifically authorized by Special Instructions herein, or by timetable bulletin.

All trains must run carefully during and after heavy storms, particularly when the track is apt to be affected. When fog, storms or other conditions obscure track or signals, speed of trains must be so reduced as to permit strict observance of signals and **INSURE SAFETY, REGARDLESS OF TIME.**

TERRITORY		FREIGHT AND MIXED	TERRITORY		FREIGHT AND MIXED
MP	MP		MP	MP	
EASTWARD, NILAND TO CALEXICO:			WESTWARD, CALEXICO TO NILAND:		
Niland, through crossover and turnouts.....			708.88 to 699.87.....		
667.40 to 667.83 (wye switch).....			699.87 to 698.90 (Main St., El Centro).....		
667.83 to 678.40.....			698.90 to 686.80.....		
678.40 to 685.70.....			686.80 to 685.70 (Brawley).....		
685.70 to 686.80 (Brawley).....			685.70 to 678.40.....		
686.80 to 698.90.....			678.40 to 667.83.....		
698.90 to 699.87 (Main St., El Centro).....			667.83 to 667.40.....		
699.87 to 708.88 (Calexico).....			Niland, through crossover and turnouts.....		
EASTWARD ON WESTMORLAND BRANCH.....			WESTWARD ON WESTMORLAND BRANCH.....		
EASTWARD ON SANDIA BRANCH.....			WESTWARD ON SANDIA BRANCH.....		

TERRITORY		FREIGHT AND MIXED	TERRITORY		FREIGHT AND MIXED
MP	MP		MP	MP	
EASTWARD, POMONA TO CHINO:			WESTWARD, CHINO TO POMONA:		
514.2 to 518.8.....			520.3 to 518.8.....		
518.8 to 520.3.....			518.8 to 514.3.....		
EASTWARD, COLTON TO RIVERSIDE:			WESTWARD, RIVERSIDE TO COLTON:		
538.95 to 539.59.....			546.36 to 544.80.....		
539.59 to 543.78.....			544.80 to 543.78.....		
543.78 (Santa Fe crossing).....			543.78 (Santa Fe crossing).....		
543.78 to 544.80.....			543.78 to 539.59.....		
544.80 to 546.36.....			539.59 to 538.95.....		
EASTWARD, BRYN MAWR TO CRAFTON:			WESTWARD, CRAFTON TO BRYN MAWR:		
544.50 to 546.60.....			551.40 to 549.90.....		
546.60 to 549.90 (over streets).....			549.90 to 546.60 (over streets).....		
549.90 to 551.40.....			546.60 to 544.50.....		

Trains with class of engine shown below are further restricted between points shown, as follows:

CLASS ENGINES	CHINO BRANCH	RIVERSIDE BRANCH	REDLANDS BRANCH
	MP 519.95 TO MP 520.30	MP 545.40 TO MP 546.36	MP 544.50 TO MP 546.00
BS-412, ES-410, FS-412, AS-410.....		15	
FP-624.....	15	10	15
BS-616B.....		X	
EF-415, EP-415.....		15	

X—Not permitted to operate.

BALDWIN PARK BRANCH	MPH	SAN BERNARDINO BRANCH	MPH
Maximum speed.....	30	San Bernardino (City limits).....	20
Except as follows:		Except: Rialto Ave. and F St.....	10
El Monte (crossings).....	15	Colton (City limits).....	15
San Gabriel River Bridge and curve at East End.....	15		
Baldwin Park (Main Ave.).....	20	BASSETT BRANCH	
Baldwin Park (curve at Ramon Blvd.).....	10	Maximum speed.....	20
Baldwin Park to Lone Hill (crossings).....	20		
La Verne (curve).....	15	AZUSA BRANCH	
Lincoln Avenue.....	20	Maximum speed.....	20
Pomona (Fulton Rd. to Claremont-Mills Ave.).....	20		
Upland (City limits).....	20	YUMA VALLEY RAILROAD	
Except: Euclid Ave. to Third Ave.....	10	0.10 to 0.53.....	10
Alta Loma (Hellman Ave., Base Line Ave. and Amethyst St.).....	25	0.53 to 14.70.....	25
Rialto to Bench.....	25	14.70 to 18.09.....	10

SPECIAL INSTRUCTIONS—TERMINAL SUBDIVISION

RULE 10-J. Speed signs to left of track:

Eastward	Reading	Westward	Reading
		MP 490.36	6

Speed signs to right of track, but with one track intervening:

Westward at MP 486.30 reading 10 is to right of drill track and beyond Alameda St.

Westward at MP 488.10 reading 12 is to right of drill track.

Eastward at MP 501.24 reading 15.

RULE 14. On Santa Monica, Hollywood and Alla Branches Trombone Whistle only is to be used, the use of Air Horn is prohibited.

The use of air horn or whistle is prohibited in Huntington Park between Alameda St. and State St., inclusive, except in emergency.

RULE 83. Extra trains or engines operating in below listed territories must register destination of trip (turning point), and date and time of departure in column captioned "Signals." When trip has been completed, date and time of arrival at initial station of trip must also be entered in column captioned "Signals." Engines en route into these territories must not leave the initial station until it has been ascertained from the train register that all preceding engines via the route to be used have completed their trips and registered time and date of arrival at initial station of trip accordingly:

Territory	Register Location
Yorba Linda Branch:	
Fullerton Junction-Yorba Linda	Fullerton Junction
Tustin Branch:	
Marlboro-Tustin	Marlboro
Stanton Branch:	
Stanton-Huntington Beach	Stanton
West Santa Ana Branch:	
Stanton-West Santa Ana	Stanton
East Long Beach Branch:	
Dominguez Junction-End of Branch	Dominguez Junction
Torrance Branch:	
South Los Angeles-Torrance	South Los Angeles
Alla Branch:	
Culver Junction-Inglewood	Culver Junction
Santa Monica Branch:	
Culver Jct.-Santa Monica	Culver Junction
Hollywood Branch:	
Culver Jct.-Hollywood	Culver Junction

Extra trains or engines with home terminal at Torrance will not operate beyond Dolanco (190th Street), except under flag protection and in accordance with Rule 99.

RULE 93. Yard limits in which the provisions of Rule 93 will apply, except within CTC limits, are established at the following points:

West MP	East MP
471.20	Los Angeles (Santa Ana Branch) .489.99
490.00	Ardmore (Santa Ana Branch)End of Branch
497.60	Studebaker (Puente Branch)501.23
509.0	Anaheim (Stanton Branch)End of Branch
511.9	South Anaheim (Tustin Branch) . .End of Branch
511.57	City of Industry (Puente Branch, includes both legs of wye)512.67
466.19	Los Angeles (San Pedro Branch) .489.90
489.91	South Gate (San Pedro Branch) . .End of Branch (also includes Long Beach Branch)

West MP	East MP
2.5	Los Angeles (Clement) (Wilmington Branch)Watson 16.9
13.1	Dominguez (East Long Beach Branch)East Long Beach 19.8
7.5	Watts (El Segundo Branch)ElSegundo 18.6
9.8	So. Los Angeles (Torrance Branch) .End of Branch
2.5	Los Angeles (Clement) (Santa Monica Branch)Santa Monica 16.8
9.0	Culver Jct. (Alla Branch)End of Branch
4.5	Alla (Inglewood Branch)End of Branch
13.6	Tallamantes (Hollywood Branch) .End of Branch
7.5	Watts (West Santa Ana Branch) . .End of Branch
4.2	Slauson Junction (Yorba Linda Branch)End of Branch
25.0	Los Alamitos Jct. (Los Alamitos Branch)End of Branch
10.5	Fullerton Junction (Anaheim Branch)Fullerton 17.3
14.4	Santa Fe Springs (Whittier Branch) .End of Branch

Los Angeles Yard: Revolving red light on post top end of A Yard when displayed, will be an indication for westward movement to stop clear of any eastward movement until light is extinguished.

MAIN LINE TOWER

Tracks 2 to 10 inclusive, crossover between 30 lead and 40 lead east end "A" Yard and tracks 1 through 8 west end "C" Yard are equipped with electrically controlled switches and switch point indicators. Indicators do not indicate track occupancy, but will display green aspect when switch is in normal position and yellow aspect when switch is in reverse position. When indicator light is not lighted, careful examination of switch must be made before making movement over switch.

Trains or engines entering "A" or "C" units through crossovers MP 479.31 and MP 479.51 must not continue movements on yard leads unless proceed signal received from yardmen (green flag by day, green light by night), or engineer orally authorized by yardman, or No. 80 (governing eastward movement), or No. 90 (governing westward movement) displayed by track indicator on top Switchtender's tower.

Flashing light track indication signs located on top of main line tower MP 479.40 governing movements on yard tracks only in lieu of hand signals or communication with herder in tower. Trains or engines must remain at clear point of yard tracks until flashing white number displayed on indicator and when displayed will be authority for train or engines occupying track designated to proceed.

When zeros are displayed singly or in multiples on the board on top of Main Line Switchtender's Tower any and all movements on track controlled by the Main Line Switchtender must stop.

Between Mission Tower and Dayton Ave. Tower, via East Bank Jct., trains or engines may use main tracks, in either direction, being governed by signal indication.

Trains or engines stopped by interlocking signal at signal bridges 3, 4 or 6 will, if signal does not clear, call operator on telephone located on signal bridge.

Trains entering or leaving east end Links or Bullring must receive proceed signal or verbal authorization.

Through engine movements between Slauson Junction and Los Nietos must not leave either of those two points until member of crew communicates with Los Nietos and it has been ascertained there are no opposing movements. Road switchers must yield to through hauler movements promptly to avoid delay.

Wilmington Branch:

Eastward trains to Dolores must contact Dolores before passing 92nd Street.

Eastward trains to Yorba Linda Branch must contact Los Nietos before passing Slauson Junction.

Westward trains to Yorba Linda Branch must contact Los Nietos before passing 92nd Street.

All engines and trains en route to Pier A or San Pedro via Dolores or Long Beach must have permission from Harbor Belt Line Yardmaster before entering Harbor Belt Line Zone of Operation.

All trains leaving San Pedro Yard en route to Dolores or beyond will not pass Sixth Street, San Pedro, until they have first received permission from Harbor Belt Line Yardmaster.

RULE 93 applies to all trains or engines operating on Harbor Belt Line Railroad.

RULE 98. The following railroad crossings at grade are not protected by interlocking. Trains and engines operating on the following branches must approach crossing with caution, and may move over crossing without stopping if crossing is clear, and no movement is approaching from either direction.

Branch	Crossing	Location
Yorba Linda...	San Pedro Branch	Los Angeles (Alameda St.)
San Pedro....	East Long Beach Branch	Dominguez
San Pedro....	ATSF	McFarland Ave. (HBL)
San Pedro....	West Santa Branch	MP 491.30
Long Beach...	ATSF (Texas Co. Spur)	MP 501.90

The following railroad crossings at grade are not protected by interlocking. Trains and engines operating on the following branches must stop, and not proceed until it has been ascertained that there are no movements approaching from either direction.

Branch	Crossing	Location
San Pedro....	Yorba Linda Branch	Los Angeles (Alameda St.)
E. Long Beach	San Pedro Branch	Dominguez
E. Long Beach	UP Railroad	Cota
El Segundo...	ATSF	Wise Transfer

On above crossings when inclement weather impairs vision, fuses must be displayed not less than 100 feet each side of crossing.

RULE 99.

Engines may proceed without train order authority between yard limit signs under protection of flagman as prescribed by Rule 99, as follows:

- San Pedro Branch-South Gate MP 489.90 to 489.91.
- Santa Ana Branch-Ardmore MP 489.99 to 490.00.

RULE 103-A. Public Utilities Commission orders require that trains and engines must stop, and member of crew protect traffic on the following street or highway crossings before movement is made:

Location	Crossing
Los Angeles Yard	Wilson Street
Los Angeles Yard	Mateo Street
Los Angeles Yard	Lyon Street
Alhambra	Mission Road (all crossings)
Lynwood	Alameda Street
Marlboro	Grove Avenue
Santa Ana	Fourth Street
E. Long Beach	Obispo Avenue

Downey: Woodruff Avenue on Royal Drill Track. Trainmen must insert switch key in lock box located at "STOP" sign either side of crossing. This will lower gate for 40 seconds and allow train to occupy crossing. Gates will remain down until train has cleared crossing.

Hooper Yard:

Protection to traffic must be afforded when switching over 8th Street.

West Anaheim: Between 6:00 AM and 4:00 PM, when switching Home Oil Company spur, gate across track must be in position to protect vehicular traffic over crossing and return to position across track after switching completed.

RULE 104. The normal position of rigid switches at junction points is as follows:

- Firestone Park... Santa Ana Br., for westward freight lead.
- Wilmington (Anaheim Blvd.)... Long Beach Br., for San Pedro Branch
- Watson... San Pedro Br., normal position of spring switch at east end of crossover for Wilmington Branch.
- Wilmington (Anaheim Blvd.)... Normal position of switch at junction of Long Beach Br. and San Pedro Br., MP 510.309, for Long Beach Branch.
- 97th Street... For Wilmington Branch.
- Watts... For Wilmington Branch.
- Dominguez... For Wilmington Branch.
- South Los Angeles... For Torrance.
- Torrance... For Harbor City.
- Culver Jct... For Santa Monica.
- West Los Angeles... For Hollywood.
- City of Industry... Puente Branch, for connecting track.
- West Anaheim... Stanton Branch, for Santa Ana Branch.
- South Anaheim... Tustin Branch, for Santa Ana Branch.
- Colima... For SPCo.
- Fullerton Jct... For UPRR.
- Stanton... Stanton Branch.

NORMAL POSITION OF WYE SWITCHES:

Location:	Leg of Wye:	For:
City of Industry	East	Extension track
Studebaker	East	Puente Branch
Studebaker	West	Puente Branch
Wilmington (Anaheim Blvd.)	West	Long Beach Br.

RULE 292. Los Angeles Yard: Flashing white lights are located on in and outbound engine leads between the Roundhouse and top end of A Yard.

Eastward engines must not proceed east of signal governing movement unless flashing white light is displayed. Engine must be within 250 feet of signal before indication will be displayed.

Roundhouse receiving Tracks Nos. 1 through 3, inclusive, are equipped with electrically controlled switches and switch-point indicators. Indicators do not indicate track occupancy, but will display green aspect when switch is in normal position, and yellow aspect when switch is in reverse position.

When indication is not lighted, careful examination of switch must be made before making movement over switch.

Westward engines must stop within 100 feet of signal located at clear point on outbound engine lead, unless flashing white light is displayed. Switch dividing inbound and outbound engine leads is a spring switch.

RULE 306. The following block signals equipped with triangular plate bearing the letter "P" have included in their control limits some special protective device. Interlocking signals are listed as "P-I." Absolute signals are listed as "P-A."

Eastward Signal	Protection	Westward Signal
P-I	Spring switch, west end track No. 1, Studebaker	P-I
	Spring switch, east end track No. 1, Studebaker	P-I
	Spring switch beginning double track Slauson Junction (Yorba Linda Branch)	P-I
	Spring Switch beginning double track Slauson Junction (Wilmington Branch)	P-I

RULE 505. AUTOMATIC BLOCK SIGNAL SYSTEM

Los Angeles Yard: Signals 4781 and 4783 top end "A" Yard lead track governs movement through crossover between yard lead and Main tracks to westward Main track with the current of traffic only.

These signals will remain dark until crossover switches are opened.

Eastward freight trains must not pass signal 4780, top end of A Yard unless proceed signal or verbal authorization is received.

RULE 512. Semaphore type block indicator (Rule 298, Figure 1) located at clear point East Long Beach Branch. Westward engines entering Wilmington Branch at Dominguez must stop and operate push button. If block is unoccupied indicator will clear (Rule 298, Figure 3). Movement may proceed.

RULE 535. SPRING DERAILS

Location	Normal Position
River Station.....	Eastward track.....Derailing
River Station.....	Westward track.....Derailing
River Station.....	Links track.....Derailing
River Station.....	Water Hole track.....Derailing
River Station.....	Bull Ring track.....Derailing
River Station.....	Hotel track.....Derailing

Derails must be lined by hand for eastward movements, and must be immediately restored to derailing position after movement is completed, and under no circumstances may spring derails be left unattended in closed position.

When spring switch or derail is equipped with switch point indicator, indicators do not indicate track occupancy, but will display a green aspect when switch is in normal position. When red aspect is displayed or light is out careful examination of switch must be made before passing over switch.

RULE 538. SPRING SWITCHES

Not equipped with facing point locks:

Location	Normal Position
Wilmington Branch	
Slauson Jct. MP 3.05.....	Westward Main Track
MP 3.65.....	Eastward Main Track
Slauson Jct. East leg of Wye.....	Wilmington Branch
Florence.....Nadeau.....	Westward Main Track
97th Street...Graham lead.....	Eastward Main Track
Watts.....West Santa Ana Br.).....	Wilmington Branch
Watts.....El Segundo Branch.....	Wilmington Branch
Watts.....End of double track.....	Westward Main Track
El Segundo Branch	
Watts.....End double Track.....	Westward Main Track
Yorba Linda Branch	
Holmes Ave...East end Wye.....	For east leg of wye
West Santa Ana Branch	
Watts.....End double Track.....	Westward Main Track
Santa Ana Branch	
Studebaker...West Switch No. 1.....	Track No. 1
Studebaker...East Switch No. 1.....	Main Track
San Pedro Branch	
South Gate...West end engine track...Main Track	
Watson.....Connection MP 499.98...Main Track	
Anaheim Blvd.Long Beach Br.....	Long Beach Branch

RULE 605. INTERLOCKING

Los Nietos-Studebaker: Limits extend on Puente Branch over AT&SFRy crossing from westward interlocking signal, MP 504.66 to eastward interlocking signal, NP 501.13 and from westward interlocking signal, MP 499.46 to eastward interlocking signal, MP 497.61. On Yorba Linda Branch limits extend from westward interlocking signal, MP 13.80, to eastward interlocking signal, MP 13.31.

At Studebaker, eastward trains and engines en route Los Nietos will move via Track No. 1 and westward trains and engines en route Studebaker will move via main track.

Main track between MP 498.80 and MP 497.76, Studebaker, is signalled for westward movements only and Track No. 1 which extends from MP 497.76 to MP 498.80 is signalled for eastward movements only. Before making an eastward movement on the main track between these points or before making a westward movement on Track No. 1, permission must first be obtained from operator and such movements must be made at restricted speed.

Stem of wye switch at Studebaker is a dual control switch and under control of operator. When necessary to hand throw this switch, permission must be obtained from operator and be governed by Rules 711 and 772.

Movements across AT&SFRy track, MP 501.70, under control AT&SFRy train dispatcher. When interlocking signals display stop indication, member of crew must call AT&SFRy train dispatcher for permission to move over crossing. After permission obtained from train dispatcher movement may be made only after flag protection has been provided on AT&SFRy tracks on both sides of crossing.

TUSTIN BRANCH

South Anaheim and Marlboro: Limits extend from interlocking signal on both sides of crossings of AT&SFRy at MP 512.40 to MP 514.50.

Authority for movement within interlocking limits, if signals display stop indication, must be obtained from AT&SFRy train dispatcher at San Bernardino by telephone. Power operated derails located 250 feet on either side of crossings at South Anaheim, MP 512.40. Instructions for manual operation posted in telephone compartment of instrument case. Cars must not be left standing on approach circuit located 150 feet in approach to interlocking signals at Marlboro, MP 514.50, while switching interchange track.

RULE 680. AUTOMATIC INTERLOCKING

Limits extend to interlocking signals on each side of following crossings:

Branch	Location	Crossing or Jct.
Yorba Linda	***Santa Fe Springs	ATSF Crossing
	*Bell	UPRR Crossing
Wilmington	**Slauson Jct.	Yorba Linda Br.
	*Clement	Alameda Running Track
	*Thenard	ATSF Crossing
San Pedro	*Thenard	ATSF Crossing
W. Santa Ana	*Paramount	UPRR Crossing
Santa Ana	*Patata	UPRR Crossing
Los Angeles Yard.	*Clement	Wilmington Branch Crossing
	Slauson Ave.	ATSF Crossing

*If signal indicates stop, member of crew must operate time release knob or pushbutton located in box near signal, wait a predetermined time, and if signal does not display proceed indication, proceed through interlocking limits as prescribed by Rule 663 (c). Instructions for push button operation and amount of time necessary to clear each signal are posted in push button box.

**Slauson Junction.....ATSF Ry Crossing
Eastward movements from Wilmington to Yorba Linda Branch must stop at aluminum marker post located 20 feet in advance of eastward interlocking signal, wait 20 seconds, then sound horn once to activate signal system. Movement may be conducted when switch reverses, and signal indicates proceed on diverging route.

For thru movements on Wilmington Branch, if signals indicate stop for eastward or westward movement, push button according to instructions posted in push button box.

Westward interlocking signal from Yorba Linda to Wilmington Branch will display a red aspect for movements approaching signal. After approach circuit has been occupied one minute switch will reverse, and signal will display proceed indication.

If westward movement is to be made from either Wilmington Branch or Yorba Linda Branch, and both approach circuits are occupied, operate push button bearing the name of Branch until white light above push button is displayed. After one minute signal will display proceed indication.

*****Santa Fe Springs**

Switch indicator and derail are located on each side of ATSF Railway tracks. Each derail is a spring derail that can be trailed through. A signal is located at facing point of each derail. When crossing the ATSF Railway and switch indicator shows clear, remove lock. In 50 seconds electric lock will release, then line derail and the signal will clear.

When switch indicator is at stop, trainmen, after removing lock from derail must ascertain that no movements are approaching, then place ATSF Railway signal at stop by inserting key in circuit controller at crossing and holding for 10 seconds. After 5 minutes signal will clear. If signal does not clear call ATSF Railway dispatcher. Key must not be inserted if movement is approaching, however, if it is apparent that the approaching movement will not continue over the crossing proceed as described when switch indicator is at stop.

The electric lock is equipped with two treadles. Depress upper treadle ONLY to remove lock. Depress lower treadle to unlock operating lever on derail.

RULE 705. LETTER-TYPE INDICATORS

Indicators located as follows:

- EASTWARD "W" Indicator at MP 6.30
- EASTWARD "M" Indicator with flashing white light MP 6.50.
- EASTWARD "M" Indicator with flashing white light MP 12.40
- WESTWARD "M" Indicator with flashing white light MP 12.60
- WESTWARD "M" Indicator with flashing white light MP 15.60

Eastward Indicator MP 12.40 and Westward Indicator MP 12.60 governs movements from Carson siding ONLY.

Main track "M" indicators displaying an illuminated "M" in top unit and flashing white light in lower unit indicates block clear. If "M" indicators are dark or the letter "W" is illuminated in "W" indicator, engines must stop and member of crew operate push button located at indicator. After 7 minutes for eastward engines or 9 minutes for westward engines, if block is unoccupied indicator will display proceed indication.

Eastward or westward engines in Carson siding before entering main track must operate push button and if block is clear a flashing white light will be displayed in lower unit. Member of crew will then line switch for main track. Illuminated "M" will be displayed.

Crew member of engine occupying approach circuits at above "M" indicates must operate CANCEL push button if through movement not to be made.

If proceed indicators are not displayed after push buttons have been operated, and if it is ascertained by communication or view of track that there are no opposing movements, engines may proceed with caution.

Rule 760. CENTRALIZED TRAFFIC CONTROL

PUENTE BRANCH

Limits extend from absolute signal west of Bartolo, MP 503.60, to absolute signal west of Puente, MP 512.30, and controlled by UPRR train dispatcher.

Trains operating between City of Industry and Los Nietos on Puente Branch must not leave City of Industry or Los Nietos until it has been ascertained that permission has been obtained from UPRR Train Dispatcher. Signal governing movement to UPRR displaying proceed indication, will be an indication that permission has been obtained.

Movements over UPRR crossing, MP 504.50, governed by absolute signals at crossing and controlled by UPRR train dispatcher. UPRR rules apply.

GENERAL REGULATIONS

RULE 825. When trains, engines, or cars are left standing in yards, a sufficient number of hand brakes must be set on the lower end to properly secure cars.

In addition the following will govern:

LOS ANGELES:

- A Yard.....8 brakes
- C Yard.....6 brakes
- Local Yard.....3 brakes
- Midway.....6 brakes
- Bull Ring.....6 brakes
- Cornfield.....6 brakes
- Aurant.....6 brakes
- State Street.....6 brakes
- Graham.....6 brakes

El Segundo

- Wise Transfer.....6 brakes
- Dolores.....4 brakes
- Long Beach Storage Yard Long Beach tracks 4, 5 and 6, Berth 212.....6 brakes

When less cars than required brakes, all hand brakes must be set. Brakes must be securely applied, using standard brake club to set staff brakes (except power brakes).

When necessary to release hand brakes to move a portion of the cars the same number of brakes must be set on remaining cars.

Conductor and/or engineer will be held responsible for compliance with the above.

RULE 837. Switching movements must be made with air brakes cut in on all cars, and cars MUST NOT BE DETACHED while in motion at the following locations:

WISE TRANSFER:

All tracks.

**FULLERTON—HUNTS FOOD SPUR
LONG BEACH:**

1. Across bridge at 3rd Street.
2. All ore loads.

ALLA: Flat cars 75 feet or longer must not be handled more than one at a time around curve of wye.

MISCELLANEOUS

1. Movements on Alameda St., Los Angeles, subject to city traffic signals when in operation.

2. South Gate—General Motors:

Derails in tracks equipped, must be returned to derailing position when switching completed.

BUILDING NO. 1: Movements on tracks 13 and 15 will be governed by aspect of light type indicator.

Light indicators and controls are located at entrance to building and at end of track. Controls are to be operated by crew.

Light type indications as follows:

- RED—Stop
- FLASHING RED—Back up
- GREEN—Proceed
- YELLOW—Proceed with caution

Hand and Lantern Signals may be used and supercede Light Indicators.

3. South Gate—Earle M. Jorgensen Co.:

Bays No. 6 and No. 7, Spur No. 3, have warning bells located at entrance. Be governed by instructions posted.

SPECIAL INSTRUCTIONS—TERMINAL SUBDIVISION

4. Southern Pacific employes using UPRR or ATSF railroad tracks will have in their possession while on duty copy of current booklet containing information pertaining to Operating Rules of these railroads.

Employes operating on tracks of Los Angeles Union Passenger Terminal are subject to rules of that company and are required to have copy of and be conversant with current rules and regulations of LAUPT.

5. Load Limit (car and contents):

Wilmington Branch	
*Los Angeles (J Yard) Watson.....	230,000 pounds
East Long Beach Branch.....	
	245,000 pounds
**El Segundo Branch.....	197,000 pounds
Torrance Branch	
**South Los Angeles-Torrance.....	197,000 pounds
Torrance-Harbor City.....	197,000 pounds
Santa Monica-Hollywood Branch.....	
	200,000 pounds
San Pedro Branch	
*Los Angeles-San Pedro.....	240,000 pounds
*Long Beach Branch.....	240,000 pounds
Alla-Inglewood Branch.....	
	170,000 pounds
Santa Ana Branch	
Firestone Park-Dyer.....	240,000 pounds
**Anaheim to Studebaker.....	240,000 pounds
Dyer-Costa Mesa.....	230,000 pounds
**Puente Branch.....	279,000 pounds
Stanton Branch	
**W. Anaheim-Stanton.....	240,000 pounds
Stanton-Huntington Beach.....	200,000 pounds
Tustin-Los Alamitos Branches.....	
	240,000 pounds
West Santa Ana Branch	
**Watts to Stanton.....	260,000 pounds
Stanton to W. Santa Ana.....	156,000 pounds
Yorba Linda Branch	
*Slauson Junction-Los Nietos.....	230,000 pounds
**Los Nietos-Brea Chem.....	230,000 pounds
Brea Chem-Yorba Linda.....	230,000 pounds
Whittier Branch.....	240,000 pounds

*Ore when consisting of cars in series SP 345000 to SP 345669 and SP 463500 to SP 463999 may be handled not to exceed 279,000 pounds.

**Gross weight of 315,000 pounds applies to uniformly loaded four axle cars with minimum axle spacing of 6 feet 0 inches and minimum distance of 37 feet 0 inches between truck centers; also, with wheels 38 inches or more in diameter.

Unless authorized by Superintendent, heavier loads must not be handled.

6. LOCATION OF OVERHEAD AND SIDE STRUCTURES NOT STANDARD CLEARANCE ON MAIN TRACK AND SIDINGS

MP	Location	Description
480.70	Dayton Ave., Overhead crossing.....	Overhead
481.72	River Station, Overhead crossing.....	Overhead
482.60	Los Angeles..... 2nd crossing, L.A. River Bridge.....	Overhead and Side
492.64	Patata, L.A. River Bridge.....	Overhead and Side
514.00	East of South Anaheim, Santa Ana River Bridge.....	Overhead and Side
18.42	(E. Long Beach Br.) Orange and Hill Overpass.....	Overhead
30.75	West Santa Ana, Santa Ana River Bridge.....	Overhead and Side

7. SPEED RESTRICTIONS FOR OTHER THAN MAIN TRACKS

	With Caution Not Exceeding MPH
Through sidings.....	15
Through yard and other tracks, wyes, ballon tracks, crossovers and turnouts, slip switches	10
HBL track east of Fries Ave. (MP 503.50)...	10
River Station and Mission Tower.....	10
On balloon track connecting Los Nietos, between Puente and Yorba Linda branches....	15

Los Angeles: Following maximum speed for trains and engines while on UPRR tracks (East Bank line) must not be exceeded:

	Passenger trains	All other trains
Pasadena Jct. to First St.....	15	15
First St. to Ninth St. Jct.....	50	25
Ninth St. Jct. to Downey Road.....	25	20

SPECIAL INSTRUCTIONS—TERMINAL SUBDIVISION

SPEED RESTRICTIONS FOR TRAINS: Maximum speed of trains in territory shown below is subject to further restrictions applicable to engines in the train as shown in **SPEED RESTRICTIONS FOR ENGINES** appearing on page 4, and **MAXIMUM SPEED PERMITTED WITH CERTAIN EQUIPMENT** and **OTHER MAXIMUM SPEEDS** appearing on pages 3 and 4 of Special Instructions for All Subdivisions. Speed must be further reduced as prescribed by speed signs, except as specifically authorized by Special Instructions herein, or by timetable bulletin.

All trains must run carefully during and after heavy storms, particularly when the track is apt to be affected. When fog, storms or other conditions obscure track or signals, speed of trains must be so reduced as to permit strict observance of signals and **INSURE SAFETY, REGARDLESS OF TIME.**

TERRITORY		FREIGHT AND MIXED	TERRITORY		FREIGHT AND MIXED		
MP	MP		MP	MP			
EASTWARD, DAYTON AVE. TOWER TO WILMINGTON (ANAHEIM BLVD.): 480.65 to 485.55 (along or across streets)..... 485.55 to 487.25 (along or across streets)..... 487.25 to 487.39 (interlocking)..... 487.39 to 489.10..... 489.10 to 493.30..... 493.30 to 501.40.....			10 12 10 15 30 20	WESTWARD, WILMINGTON (ANAHEIM BLVD.) TO DAYTON AVE. TOWER: 501.40 to 493.30..... 493.30 to 489.10..... 489.10 to 487.39..... 487.39 to 487.25 (interlocking)..... 487.25 to 485.55 (along or across streets)..... 485.55 to 480.60 (along or across streets).....			20 30 15 10 12 10
EASTWARD, WILMINGTON (ANAHEIM BLVD.) TO LONG BEACH: 501.31 to 502.32..... 502.32 to 502.40..... 502.40 to 503.59.....			15 10 15	WESTWARD, LONG BEACH TO WILMINGTON (ANAHEIM BLVD.): 503.59 to 502.40..... 502.40 to 502.32..... 502.32 to 501.31.....			15 10 15
EASTWARD, FIRESTONE PARK TO COSTA MESA: 489.10 to 491.92..... 491.92 to 492.00 (interlocking)..... 492.00 to 509.00..... 509.00 to 511.20..... 511.20 to 516.39..... 516.39 to 517.40..... 517.40 to 519.40..... 519.40 to 521.70.....			30 20 30 15 30 15 30 20	WESTWARD, COSTA MESA TO FIRESTONE PARK: 521.70 to 519.40..... 519.40 to 517.40..... 517.40 to 516.39..... 516.39 to 511.20..... 511.20 to 509.00..... 509.00 to 492.00..... 492.00 to 491.92 (interlocking)..... 491.92 to 489.10.....			20 30 15 30 15 30 20 30
EASTWARD, WEST ANAHEIM TO STANTON: 509.00 to 513.60..... 513.60 to 513.97.....			30 15	WESTWARD, STANTON TO WEST ANAHEIM: 513.60 to 509.00..... 513.97 to 513.60.....			30 15
EASTWARD, SOUTH ANAHEIM TO TUSTIN: 511.90 to 512.22..... 512.22 to 512.60 (crossing)..... 512.60 to 514.53..... 514.53 to 514.91 (crossing)..... 514.91 to 522.40.....			20 15 20 15 20	WESTWARD, TUSTIN TO SOUTH ANAHEIM: 522.40 to 514.91..... 514.91 to 514.53 (crossing)..... 514.53 to 512.60..... 512.60 to 512.22 (crossing)..... 512.22 to 511.90.....			20 15 20 15 20
EASTWARD, STUDEBAKER TO CITY OF INDUSTRY: 497.57 to 497.75..... 497.75 to 500.00..... 500.00 to 501.27..... 501.27 to 504.93..... 504.93 to 504.98 (through switches)..... 504.98 to 511.48 (UPRR)..... 511.48 to 512.66.....			10 30 15 30 20 #.. 20	WESTWARD, CITY OF INDUSTRY TO STUDEBAKER: 512.66 to 511.48..... 511.48 to 504.98 (UPRR)..... 504.98 to 504.93 (through switches)..... 504.93 to 501.27..... 501.27 to 500.00..... 500.00 to 497.75..... 497.75 to 497.57.....			20 #.. 20 30 15 30 10

#Trains must not exceed 20 MPH through junction switches UPRR tracks. Speed on UPRR tracks governed by UPRR rules, special rules and instructions.

Trains with class of engine shown are further restricted between points shown below as follows:

CLASS OF ENGINE	SANTA ANA BRANCH			STANTON	TUSTIN BRANCH		
	MP 489.10 491.80	MP 497.67 503.43	MP 503.43 517.39		MP 515.00 516.69	MP 517.70 518.92	MP 519.22 519.77
BS-412, ES-410, FS-412, AS-410.....							15
EF-418, EP-418.....	20	20					10
AS-418.....	15	15	25	25	15	15	10
EF-415, EP-415.....	25	25					15

SPECIAL INSTRUCTIONS—TERMINAL SUBDIVISION

SPEED RESTRICTIONS FOR TRAINS: Maximum speed of trains in territory shown below is subject to further restrictions applicable to engines in the train as shown in **SPEED RESTRICTIONS FOR ENGINES** appearing on page 4, and **MAXIMUM SPEED PERMITTED WITH CERTAIN EQUIPMENT** and **OTHER MAXIMUM SPEEDS** appearing on pages 3 and 4 of Special Instructions for All Subdivisions. Speed must be further reduced as prescribed by speed signs, except as specifically authorized by Special Instructions herein, or by timetable bulletin.

All trains must run carefully during and after heavy storms, particularly when the track is apt to be affected. When fog, storms or other conditions obscure track or signals, speed of trains must be so reduced as to permit strict observance of signals and **INSURE SAFETY, REGARDLESS OF TIME.**

	MPH		MPH
WILMINGTON BRANCH		HOLLYWOOD BRANCH	
Maximum Speed.....	30	Maximum speed.....	20
Santa Barbara Ave. to 103rd St. crossings.....	25	Talamantes and Soldier Home spur crossings.....	15
Florence Avenue.....	20	Except Sepulveda Blvd., Pico Blvd., Olympic Blvd., and Ohio Ave.....	10
Abila, Wilmington Ave. Compton crossings.....	20	Westwood Blvd. and between Wilshire Blvd. and Canon Drive.....	10
Rosecrans Ave. to Alondra St.....	20	Crescent Drive and Rexford Drive.....	5
Dolores and Carson St.....	20	Beverly Blvd., Doheny Drive and Seward St.....	10
Watson, Sepulveda Blvd.....	20		
Long Beach Circle Bridge.....	10	ALLA BRANCH	
Ore trains over the following bridges:		Maximum speed.....	20
*FIRESTONE BRIDGE.....	15	Culver City, Washington Blvd., Madison Ave., Motor Ave., Overland Ave. and Elinda St.....	15
COMPTON CREEK BRIDGE.....	15		
*No westward movements may be allowed on this bridge until the ore train has cleared the bridge.		INGLEWOOD BRANCH	
		Maximum speed.....	15
EAST LONG BEACH BRANCH		WEST SANTA ANA BRANCH	
Maximum speed.....	30	Maximum speed.....	30
Los Cerritos Bridge and Spring St.....	25	Wilmington Ave., Imperial Highway, Paramount Blvd., Compton Blvd., Center St., Lincoln Ave., Verano St., Harbor Blvd., 17th St. and 5th St.....	25
North Long Beach to East Long Beach crossings.....	15	Long Beach Blvd., Atlantic Ave., Lakewood Blvd., Bellflower Blvd., Pioneer Blvd. and Stanton Blvd.....	15
Stop before crossing Del Amo Blvd.....		Nelson St. and Garden Grove Blvd., Garden Grove.....	10
EL SEGUNDO BEACH		STANTON BRANCH	
Maximum speed.....	30	Maximum speed.....	30
Compton Ave., Central Ave., and Main St.....	20	Stanton (Garden Grove Blvd.).....	25
South Broadway and Figueroa St. and crossings between Delta and Inglewood Aves.....	15	Huntington Beach (Clay St., 17th St.).....	25
Sepulveda and El Segundo Blvd.....	10	YORBA LINDA BRANCH	
TORRANCE BRANCH		Maximum speed.....	30
Maximum speed.....	30	Holmes Ave. to Los Nietos Jet. crossings.....	20
120th St., Laconia and Olympic Blvd. and 132nd St.....	20	Alameda St., Atlantic Ave. crossings.....	20
Curve south of Rosecrans Ave.....	15	Ore trains over the following bridges:	
Strawberry Park curve.....	10	San Gabriel River Bridge.....	15
Curve north and south of Gardena Station.....	10	Rio Hondo River Bridge.....	15
190th St.....	15	Los Angeles River Bridge.....	10
Bridge at Torrance, Torrance Station and Carson St.....	15	WHITTIER BRANCH	
Sepulveda Blvd. Highway 101.....	20	Maximum speed.....	15
Harbor Blvd.....	10	LOS ALAMITOS BRANCH	
SANTA MONICA BRANCH		Maximum speed.....	30
Maximum speed.....	30		
Nevin and Flower St. crossings.....	10		
Flower St. and Cloverfield Blvd. crossings.....	20		
Culver Jet. and Overland Ave. crossings.....	15		
Overland Ave. and Santa Monica (14th St.).....	20		